

## **Toolbox Installation Instructions**

- Option 1: Step 1 Position toolbox in truck bed across rails and center from side to side.
  - **Step 2** Drill one 1/8" hole through the center of each end of the box and bed rail where the box rests on the bed rails of the truck.
  - **Step 3** Fasten toolbox to the bed rails with two #14 sheet metal screws (not included) through the 1/8" holes.
- Option 2: Step 1 Position toolbox in truck bed across rails and center from side to side.
  - **Step 2** Make a mark on the underside of the box where it meets the edge of the bed rail.
  - **Step 3** Take the box off of the truck and make another mark 5/16" in towards the center of the box.
  - **Step 4** Drill a 9/32" hole centered from front to rear and on the new mark.
  - **Step 5** Place toolbox on the truck bed and fasten with two ¼" J bolts on each side of the truck. The J bolts will hook around the edge of the truck bed rail and the threaded end will go through the 9/32" holes. Fasten with two ¼" nuts and washers (J bolts, nuts, and washers not included).



Lund International 800-241-7219 • Visit us at lundinternational.com

© 2012 Lund International, Inc. All rights reserved. Lund® and the Lund® logo are trademarks of Lund International, Inc.



