

Supplemental instructions for extra step pad installation.

#10264

(If you have a 3 or 4 door vehicle, please follow these directions for installing the extra step pad.)

- 1. Measure 4" forward from the edge of the end cap. This will mark the placement for the back edge of the pad.
- 2. Clean the area where the step pad is to be applied with Isopropyl Alcohol if there is any oil or wax on the running board.
- 3. Peel the two plastic adhesive covers off the left end of the step pad for the driver's side, or off the right end for the passenger side.
- 4. Place the end of the step pad that still has the plastic covers on it at the 4"mark on the running board. Hold this end down while flexing the other end up. When the pad is straight, press the adhesive end down to the running board. Lift up the other end of the step pad and remove the plastic protective strips. Press this end down to the running board.

Note: Please be sure that you have proper alignment of the pad on the board before pressing the adhesive side down. The adhesive backing is very strong and once the pad is placed onto the board, it will be very difficult to remove it.



Lund International
800-241-7219 • Visit us at lundinternational.com
© 2012 Lund International, Inc. All rights reserved.
Lund® and the Lund® logo are trademarks of Lund International, Inc.