

HOOD PROTECTOR INSTALLATION INSTRUCTIONS

- Raise the hood of the vehicle and remove any dirt or debris. Clean the top and underside of the hood with a mixture of mild detergent and water. Rinse and allow to dry completely.
- 2 Dry fit the hood protector to the hood to check the fitment and to take note as to where the adhesive taped tabs will adhere to the hood.
- 4 Using the alcohol pad provided in the hardware pack, clean the areas of the hood where the adhesive on the mounting tabs will adhere.
- KIT CONTAINS: HOOD PROTECTOR TOOLS NEEDED: ISOPROPYL ALCOHOL CLEAN CLOTH

KIT CONTAINS:

CLEAN CLOTH

HOOD PROTECTOR **TOOLS NEEDED:**

ISOPROPYL ALCOHOL

- 6 Remove the red backing from the adhesive on the 3 center mounting tabs. Center the hood protector on the hood and align the contours of the tabs with the contours of the hood and press into place.
- 6 Using isopropyl alcohol, clean the outer surface of the hood above the headlight and allow to dry. Remove the red backing from the adhesive on the outer tabs. Adhere the outer mounting tabs of the hood protector to the outer surface of the hood above the headlight.

OPTIONAL: Self piercing screws are included in the hardware pack to attach the three center tabs if a screw on application is desired

CLEANING: USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.

IMPORTANT INFORMATION

AFTER INSTALLING THE HOOD PROTECTOR CHECK FOR FIT. MAKE SURE THE HOOD PROTECTOR IS NOT TOUCHING THE PAINT IN ANY SPOTS THAT MAY CAUSE RUBBING BY VEHICLE VIBRATION AS THIS INDICATES AN IMPROPER INSTALLATION. IF YOUR APPLICATION REQUIRES BUMP-ONS MAKE SURE THEY ARE INSTALLED PROPERLY.

STAMPEDE WILL NOT PAY FOR PAINT TOUCH UPS OR REPAINTS ON HOODS DUE TO IMPROPER INSTALLATION.

IF YOU HAVE A PRODUCT THAT USES 3M REDLINE AND HAVE TROUBLE REMOVING THE RED BACKING, USE A DROP OF ISOPROPAL ALCOHOL OR NAPHTHA ON THE EDGE OF THE BACKING AND THIS WILL ALLOW THE BACKING TO LOOSEN THUS ALLOWING YOU TO PEEL THE BACKING OFF THE TAPE.

Stampede Automotive Accessories • 1924 S. Washington Blvd. • Camanche, IA. 52730 • Ph 563-259-9189 Fax 563-259-9288 • www.stampedeautomotiveaccessories.com



HOOD PROTECTOR INSTALLATION INSTRUCTIONS

#99

- Raise the hood of the vehicle and remove any dirt or debris. Clean the top and underside of the hood with a mixture of mild detergent and water. Rinse and allow to dry completely.
- 2 Dry fit the hood protector to the hood to check the fitment and to take note as to where the adhesive taped tabs will adhere to the hood.
- 4 Using the alcohol pad provided in the hardware pack, clean the areas of the hood where the adhesive on the mounting tabs will adhere.
- 3 Remove the red backing from the adhesive on the 3 center mounting tabs. Center the hood protector on the hood and align the contours of the tabs with the contours of the hood and press into place.
- (3) Using isopropyl alcohol, clean the outer surface of the hood above the headlight and allow to dry. Remove the red backing from the adhesive on the outer tabs. Adhere the outer mounting tabs of the hood protector to the outer surface of the hood above the headlight.

OPTIONAL: Self piercing screws are included in the hardware pack to attach the three center tabs if a screw on application is desired

CLEANING: USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.

IMPORTANT INFORMATION

AFTER INSTALLING THE HOOD PROTECTOR CHECK FOR FIT. MAKE SURE THE HOOD PROTECTOR IS NOT TOUCHING THE PAINT IN ANY SPOTS THAT MAY CAUSE RUBBING BY VEHICLE VIBRATION AS THIS INDICATES AN IMPROPER INSTALLATION. IF YOUR APPLICATION REQUIRES BUMP-ONS MAKE SURE THEY ARE INSTALLED PROPERLY.

STAMPEDE WILL NOT PAY FOR PAINT TOUCH UPS OR REPAINTS ON HOODS DUE TO IMPROPER INSTALLATION.

IF YOU HAVE A PRODUCT THAT USES 3M REDLINE AND HAVE TROUBLE REMOVING THE RED BACKING, USE A DROP OF ISOPROPAL ALCOHOL OR NAPHTHA ON THE EDGE OF THE BACKING AND THIS WILL ALLOW THE BACKING TO LOOSEN THUS ALLOWING YOU TO PEEL THE BACKING OFF THE TAPE.