


## Installation Instructions

## PLEASE READ CAREFULLY


## Chevy/GMC C-K (1988-C) Standard Cab, Cab Length Club Cab, Cab Length

- 1. Preshape your stone guards by bending them over your knee or work bench to match curve of wheel well.
- 2. Attach stone guards to the running board at the end where you find the smooth weldment. Use 1/4" carriage bolts, flat washers, lock washers and nuts. (See Illustration #1.)
- 3. Align the running board with the bottom of the cab and hold in place with vise grips or c-clamps. Drill 1/8" hole through stone guard into wheel well and attach with No. 14 hex head screw. Repeat this procedure (2) more times per stone guard. (See Illustation #1.)
- 4. Attach running board to body by drilling a 11/32" hole near the back end of the board through the lip on the riser of board through the bottom of the body. Fasten together using 5/16" bolt, flat washer, lock washer, and nut. Repeat this procedure (2) more times per side on a standard cab, (3) more times on a club cab. (See Illustration #2.)
- 5. Attach angle bracket to the rear of running board using ¼" carriage bolts, flat washers, lock washers, and nuts. Bolt flat cab mount plate to angle using 5/16" bolts, flat washers, lock washers, and nuts. (See Illustration #2.)

**ILLUSTRATION #1** 




**ILLUSTRATION #2** 




6. Make sure board is level at this point. Then drill (2) 11/32" holes through back of the cab using the holes at the top of the flat cab mount plate as a guide. Attach with 5/16" bolts, flat washers, lock washers, and nuts. (See Illustration #2 and #3.)

## CLUB CAB—CAB LENGTH


- 7. Follow all procedures listed above.
- 8. Approximately 12½" towards the front tire from the back of the door there is a bolt with a nut coming through the cab floor. (See Illustration #4.)
- 9. Remove this nut and attach the pre-bent strap found in your bracket kit. Reinstall the nut leaving it slightly loose.
- 10. Attach angle to this strap and swing up under running board. Using the slots in this angle as a guide drill 2 holes (11/32") through board.
- 11. Directly above angle drill a 11/32" hole through board and body. Attach 5/16" x 2½" bolt, flat washer, lock washer, and nut. Tighten all fasteners when bracket is assembled as shown in Illustration #5.



**ILLUSTRATION #4** 



**ILLUSTRATION #5** 



10%" TOWARD THE FRONT FROM FORWARD PEDISTAL



Lund International
800-241-7219 • Visit us at lundinternational.com
© 2012 Lund International, Inc. All rights reserved.
Lund® and the Lund® logo are trademarks of Lund International, Inc.