

ASTRO, SAFARI

- 1. Slide one square headed bolt into each track.
- 2. Preshape your stone guards by bending them over your knee or work bench to match the curve of the wheel well. (See illustration #1.)
- 3. Attach the stone guards to the running board with 3/8" self-tapping bolts provided. Simply thread these bolts through stone guards and into running board tracks. (See Illustration #1.)
- 4. Near the center of the running board, attach the 15" angle. Use the square headed bolts, flat washers, lock washers and nuts. Leave these fasteners finger tight.
- 5. Hold the board up to the van. Make sure the lip of the board is against the pinch weld of the van and the stone guards are straight.
- 6. Fasten stone guards in the wheel well by drilling a 5/32" hole near the top of the stone guard and through the wheel well lip. Attach with #14 x 3/4" hex head screw. Continue this procedure using 3 screws per stone guard. (See Illustration #1.)
- 7. Along the lip of the running board, drill (3) 5/32" holes through lip and pinch weld. Attach with #14 x 3/4" screws. (See Illustration #1.)
- 8. Attach the 4 1/2" long vertical strap to the 15" angle using 5/16" bolt, flat washers, lock washers and nuts. (See Illustration #2 and #3.)
- 9. Attach the 10 1/2" long vertical strap to the end of the 15" angle using 5/16" bolt, flat washer, lock washers and nuts. (See Illustration #2 and #3.)
- 10. Attach 10 1/2" strap to the box frame of the vehicle. Using a 9/32" drill bit, drill up through the box frame using the hole in the 10 1/2" strap as a guide. Now attach strap to box frame using 5/16" thread cutters.
- 11. Tighten the nuts on 15" bracket under the running board.
- 12. Attach the 4 1/2" strap to the inner skin of the van. Using a 9/32" drill bit, drill through the inner skin using the slot in top of the 4 1/2" strap as a guide. Fasten using a 5/16" thread cutter.
- 13. See Illustration #3 for completed bracket assembly.





