


AUTOMOTIVE ACCESSORIES INSTALLATION and CLEANING

I - Sheet Number STMPD24 Rev.A

This product is designed to be placed on the outside rubber window channels of the door.





70°-100° F (Install temp.)

- Remove the plastic window guide from the channel by releasing the spring clip (store for future use if the visors are ever removed). Replace channel into
- Remove triangular plastic mirror cover on the inside door panel of vehicle, Loosen, but do not remove the forwardmost nut, to create the necessary gap behind the mirror cap to install the front flange of visor.
- Buff the outside rubber window channels where the visor will mount with a scotch brite pad, then clean with an alcohol pad. Be sure to use Surface Prep on all windows before installing the first visor to prevent Surface Prep pad from drying out.
- 4 Remove tape line from rear end flange. Expose 2" (5 cm) of tape from each end of top flange.
- 6 Align the visor with the previously prepared window surface. The front flange slides under the loosened mirror cap.
- 6 Verify proper positioning, and gently press on exposed areas of tape to secure in place.
- With the visor in its final position, remove remaining tape liner by pulling on free ends.
- Apply pressure along flange edges to ensure adhesion and secure visor in place.
- Tighten loosened nut and reinstall interior mirror cap.






IMPORTANT: Clean with a SOFT cloth and soap and water ONLY! Using abrasive cleaners, chemicals, or solvents will VOID the warranty on this product. Stampede Automotive Products • Visit us at stampedeproducts.com • 800-241-7219



EDE SIDEWIND DEFLECTOR INSTALLATION and CLEANING

I - Sheet Number STMPD24 Rev.A

This product is designed to be placed on the outside rubber window channels of the door.





70°-100° F (Install temp.)

- Remove the plastic window guide from the channel by releasing the spring clip (store for future use if the visors are ever removed). Replace channel into
- Remove triangular plastic mirror cover on the inside door panel of vehicle. Loosen, but do not remove the forwardmost nut, to create the necessary gap behind the mirror cap to install the front flange of visor.
- Buff the outside rubber window channels where the visor will mount with a scotch brite pad, then clean with an alcohol pad. Be sure to use Surface Prep on all windows before installing the first visor to prevent Surface Prep pad from drying out.
- 4 Remove tape line from rear end flange. Expose 2" (5 cm) of tape from each end of top flange.
- Align the visor with the previously prepared window surface. The front flange slides under the loosened mirror cap.
- 6 Verify proper positioning, and gently press on exposed areas of tape to secure in place.
- With the visor in its final position, remove remaining tape liner by pulling on free ends.
- Apply pressure along flange edges to ensure adhesion and secure visor in place.
- Tighten loosened nut and reinstall interior mirror cap.



