Filter replacement (synthetic)

1. Switch off the unit at the wall and wait five minutes.
2. Remove the front cover:
    1. Undo the two screws at the bottom.
    2. Lift the cover off its hooks.
3. Take out the old filter and put it in the bag supplied.
4. Fit the new filter with the arrow pointing up.
5. Refit the cover and switch the unit on.