Pump isolation procedure (synthetic)

1. Purpose

This procedure sets out how maintenance staff isolate a pump before work starts on it.

2. Procedure

1. Switch off the pump at the local control panel and attach a personal lock.
2. Close the suction and discharge valves and fit valve locks to both of them.

4. Records

The supervisor records each isolation in the permit log, with the lock numbers and the time.

Permit logs are kept for three years and are checked at each quarterly audit.

4. Review

This procedure is reviewed every two years or after any incident.