Parameters setting

- P01 Background luminance. 1 is the darkest, 3 is the brightest
- P02 Unit of the mileage. 0 is KM, 1 is MILE
- P03 Voltage grades. 24V, 36V, 48V. The original voltage is 36V.
- P04 Sleep time. 0 is without sleep, other numbers stand for the sleep time (1-60 min).
- P05 PAS grades.
 - 0, 3 grades mode: 1 grade 2V, 2 grade 3V, 3 grade 4V
 - 1, 5 grades mode: 1 grade 2V, 2 grade 2.5V, 3 grade 3V, 4 grade 3.5V, 5 grade 4V
- P06 Wheel size. Unit: inch. Precision: 0.1
- P07 Speed measuring magnet. Range: 1-100
- P08 Speed limit. Range: 0-50km/h, 50 means without limit

No-Communication Status (controlled by the meter): when the real speed is over the ones we set, the meter would shut off PWM output; when less than the speed we set, the meter would turn on PWM output automatically, the driving speed would be $\pm 1 \text{km/h}$; (Speed limit is for PAS, not for Throttle)

Communication Status (controlled by the controller): The driving speed keeps same with the ones we set. Random error: ±1km/h. (Speed limit is for both PAS and Throttle)

Notes: These data are based on KM. When changing KM to Mile, the speed value on the screen would convert to correct Miles automatically, but if you do not change the setting of speed limit from KM to Mile, it would be different from the real speed limit in Mile.

- P09 Zero start & Non-zero Start. 0 is Zero Start, 1 is Non-zero Start
- P10 Driving mode.
 - 0 is driven by PAS. Throttle is useless at this time.
 - 1 is driven by Throttle. PAS is useless at this time.
 - 2 is driven by PAS & Throttle. Throttle is useless at Zero Start status.
- P11 PAS sensitivity. Range: 1-24
- P12 PAS start strength. Range: 0-5
- P13 PAS magnet type. There are 3 types: 5, 8, and 12.
- P14 The Current-limiting of Controller. The original Current is 12A. Range:1-20A
- P15 Not implemented now.
- P16 Reset ODO. Long press the up button for 5s, ODO could be reset.