

1868 SPACE COOKIES


Sheet: / File: Pico-ButtonBoard-v1.kicad_sch

Title:

Size: B Date: 2025-12-25
KiCad E.D.A. 9.0.6

7

1




1868 SPACE COOKIES

Sheet: /Button Inputs/
File: button-input.kicad_sch

Title:

Size: B Date: 2025-12-25
KiCad E.D.A. 9.0.6

Rev: Id: 2/5



1868 SPACE COOKIES

Sheet: /Joystick Inputs/
File: joystick-inputs.kicad_sch


Title:

Size: B Date: 2025-12-25
KiCad E.D.A. 9.0.6

Rev:
Id: 3/5

- Power supply input range: 8V – 30V
- Allows use of M12 and M18 Milwaukee battery packs.
- Input power can be sourced from either a Milwaukee battery pack or an AC power adapter.
- Voltage of the battery pack may be higher than the AC adapter.
- The battery pack is disabled from supplying power whenever the AC adapter is greater than 9V.
- All inputs are protected from reverse polarity

Hot Plug




1868 SPACE COOKIES

Sheet: /Power Supply/
File: power-supply.kicad_sch

Title: Size: B Date: 2025-12-25

Rev:

1 2 3 4 5 6 7 8



1868 SPACE COOKIES

Sheet: /Board ID/
File: board-id.kicad_sch

Title:

Size: B Date: 2025-12-25
KiCad E.D.A. 9.0.6

Rev:
Id: 5/5

1 2 3 4 5 6 7 8