
Note for Model Import

Aliengo

Modifications


- 1. Replace package://aliengo_description/ with ../ in URDF.
- 2. Set flip_visual_attachments to True when loading asset.
- 3. Duplicate python/rlgpu/cfg/anymal.yaml and modify names in defaultJointAngles to Aliengo's cooresponding name.
- 4. Add Aliengo to retrieve_cfg(...) in python/rlgpu/utils/config.py . Note that both pytorch_ppo_<name>.yaml and <name>.yaml can be modified for training and model performance respectively.
- 5. Change args.task back to Anymal in python/rlgpu/utils/parse_task.py due to a builtin restriction.

Static Import



Parallelized Training

python python/rlgpu/train.py --task=Aliengo



Xiaotian

Modifications

- 1. Convert STL mesh file to either dae mesh or obj file online.
- 2. Replace package://xiaotian_description/ with ../ in URDF.
- 3. Replace .STL' with .dae or .obj in URDF.
- 4. Set flip_visual_attachments to False when loading asset.

Static Import

