micro:bit glove pocket pattern

- 1. Cut out the pattern on this page. It should measure 3.25" wide and 7" from point to bottom.
- 2. Use the pattern to cut out as many pockets as you need (one pocket per glove).
- 3. Fold the bottom of the piece to the dashed line. Sew a narrow (1/8"-1/4") seam along each long side. Turn the seams to the inside of the pocket.
- 4. Attach hook-and-loop fastener dots to the flap and the pocket. You can use adhesive fastener or sew-on.

