Samson Sr850 Detachable Cable Mod

Jeremy Lauber

Revision: 1.0

Last Revision: 11/04/2026

List of Materials / Tools:

- Super glue
- 3.5mm TRS Stereo Female Panel Mount Socket
- Thin insulated wire
- Heat-shrink tubing
- Soldering iron
- 3D printer capable of printing small parts
- Clamps

Instructions:

1. Solder wires to the socket, trim them to approximately 3 cm, and cover the socket contacts with heat-shrink tubing.
2. Print the socket housing. The material and print settings are not particularly important, but the model must be split into two halves before printing.
3. Insert the socket into the printed halves of the housing, apply glue along the edges, and clamp the halves together.
4. Remove the cover and housing around the headphone cable entry point. Take several clear photos of the existing wiring for reference. The headphones use an unbalanced connection, so the wiring is relatively straightforward, but having reference photos is helpful.
5. Unsolder the existing TRS cable and verify that the printed housing can be press-fitted into the cable-mount cavity.
6. Connect the wiring to the new socket, press-fit it into the cable mount, and reassemble the headphones.

