Lecture 11 — Memory-Mapped I/O

Jeff Zarnett & Mike Cooper-Stachowsky jzarnett@uwaterloo.ca, mstachowsky@uwaterloo.ca

Department of Electrical and Computer Engineering University of Waterloo

April 5, 2024

MTE 241 Spring 2024 1/20

Take Me There

Memory-mapped I/O – to communicate with a HW device, an area that looks like main memory really represents the HW device.

This simplifies some operations!

Kind of like how UNIX treats everything as a file...

MTE 241 Spring 2024 2/20

Port Mapped

This contrasts with the older-style port-mapped I/O

There are different CPU instructions and separate registers used to communicate with the device.



It's not that this does not work, but it's just more difficult to work with.

MTE 241 Spring 2024 3/20

I/O or Control

Maybe a better name for this is "Memory Mapped Control".

The device is controlled via setting some voltages (1s, 0s) on the chip.

If we map those to memory locations, we know how to read write the 1s and 0s to the device just as if it were memory.

MTE 241 Spring 2024 4/20

Peripheral

Hardware devices outside the CPU and memory are sometimes referred to as peripheral devices.

A peripheral is an often optional circuit that interfaces with the CPU.

Examples: UART, I2C, GPIO...

MTE 241 Spring 2024 5/20

Okay, but where are they?

The data sheet for the device will tell you where the registers are.


One option: absolute address (which is nice).

Other option: base and offset locations.

Why base and offset? Support multiple devices.

MTE 241 Spring 2024 6/20

Consult the Map



MTE 241 Spring 2024 7/20

Altenative: mmap()

An alternative use for memory-mapping in UNIX involves the use of mmap (), a function nominally used to map a file into memory.

Then, interact with the file just like memory!

MTE 241 Spring 2024 8/20

```
void* mmap( void* address, size_t length, int protection, int flag,
  int fd, off_t offset );
```

address: where you want the mapped region to go; use NULL.

length: how many bytes to map.

protection: rules for how memory can be used.

flag: mode for mapping.

fd: file descriptor of the file to map.

offset: how far from the start of the file mapping begins.

MTE 241 Spring 2024 9/20

Protection Flags

Valid values are PROT_NONE, PROT_READ, PROT_WRITE, and PROT_EXECUTE.

They can be combined with the bitwise OR operator.

Whatever flags you choose have to be consistent with how the file was opened with open.

MTE 241 Spring 2024 10/20



What's the point of PROT_NONE, if all things are forbidden?


Flags can be one of two options: MAP_PRIVATE or MAP_SHARED.

Private: modifications are not visible to other processes mapping the same file and not written out to the underlying file.

Shared: modifications are visible to other processes and written out to the file... but maybe not instantly.

MTE 241 Spring 2024 12/20

Memory Mapped File



MTE 241 Spring 2024 13/20

Protection

If we wish to change the protection rules for a section, we use mprotect.

```
int mprotect( void* address, size_t length, int prot );
```

address: the memory to modify protection of.

length: the size of said memory.

prot: the new protection rules.

MTE 241 Spring 2024 14/20

Synchronize



```
int msync( void* address, size_t length, int flags );
```

address: the memory to synchronize.

length: how many bytes to synchronize.

flags: mode for synchronization; use MS_SYNC (blocking).

MTE 241 Spring 2024 15/20

Unmap

```
int munmap( void* address, size_t length );
```

address: the memory to unmap.

length: how many bytes to unmap.

A segment would be unmapped automatically when a process exits, but as always it is polite to unmap it as soon as you know that you are done with it.

MTE 241 Spring 2024 16/20

Memory Mapping Example

```
#define XOPEN SOURCE
#include < stdio.h>
#include < stdlib .h>
#include < svs/shm.h>
#include < string . h>
#include <unistd h>
#include < sys/wait.h>
#include <sys/stat.h>
#include <fcntl.h>
#include < sys/mman.h>
int main( int argc. char** argv ) {
    int fd = open( "example.txt", 0_RDWR );
    struct stat st;
    stat( "example.txt", &st ):
    ssize_t size = st.st_size:
    void* mapped = mmap( NULL, size, PROT_READ | PROT_WRITE, MAP_SHARED, fd, O );
```

MTE 241 Spring 2024 17/20

Memory Mapping Example

```
int pid = fork();
if ( pid > 0 ) { /* Parent */
    waitpid( pid, NULL, 0 );
    printf("The_new_content_of_the_file_is:_%s.\n", (char*) mapped);
    munmap( mapped, size );
} else if ( pid == 0 ) { /* Child */
    memset( mapped, 0, size ); /* Erase what's there */
    sprintf( mapped, "It_is_now_Overwritten");
    /* Ensure data is synchronized */
    msync( mapped, size, MS_SYNC );
    munmap( mapped, size );
}
close( fd );
return 0;
```

MTE 241 Spring 2024 18/20

The Example is... Flawed

The example works acceptably in the sense that we successfully overwrite the data with the new data and the parent process sees the change.

But things get weird if we tried to write fewer bytes than the original message.

In general, the mapped area size cannot change.

Linux has mremap but this is not portable...

MTE 241 Spring 2024 19/20

Memory-Mapped Files

How does it work, though?

Basic premise: disk blocks mapped to main memory.

First access is a page fault; subsequent accesses are reads/writes.

MTE 241 Spring 2024 20/20