

# NX<sup>™</sup> CONTROL PANEL DIMMING CARD INSTALLATION INSTRUCTIONS

#### **DESCRIPTION**

The NX Commercial Lighting Control Panels Dimming Card is shipped individually from the CX Panel. The following information describes the NXP-DIM8 installation.

#### **PRECAUTIONS**

- READ AND FOLLOW ALL SAFETY INSTRUCTIONS.
- CAUTION RISK OF ELECTRICAL SHOCK. To prevent electrical shock, turn off power at the circuit breaker before installing or servicing
  unit. Never wire energized electrical components.
- NOTICE: For installation by a licensed electrician in accordance with National and/or local Electrical Codes and the following
  instructions.
- CAUTION: USE COPPER CONDUCTOR ONLY.
- Be sure to read and understand all instructions before installing or servicing unit
- For Indoor use only. Do not use outdoors.
- Do not mount near gas or electric heaters.
- Disconnect switch or a circuit breaker must be provided and marked as the disconnecting device.
- The use of accessory equipment not recommended by the manufacturer may cause an unsafe condition.
- Confirm that device ratings are suitable for application prior to installation.
- No user serviceable parts contained inside unit. Refer all service related questions to the factory.
- All servicing shall be performed by qualified service personnel.
- Equipment should be mounted in locations and at heights where it will not readily be subjected to tampering by unauthorized personnel.
- · Use only approved materials and components (i.e. twist on connectors, electrical box, etc.) as appropriate for installation.
- NOTICE: Do not install if product appears to be damaged.
- If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.
- Do not use this equipment for other than intended use.

## **SAVE THESE INSTRUCTIONS!**


#### **INSTALLING INDIVIDUAL DIMMING CARDS**

Caution: ALWAYS remove supply power to the Panel control popwer supply prior to making any connections between dimming boards and panel processor board. Failure to do so may result in personnel injury, damage to the panel, and void its warranty


Disconnect power from the panel. Remove the NXP-DIM8 from its packaging. Review the connector on the back of the card. You must align the card so that the keying symbol aligns correctly with the *NX* Panel board.



Locate Option connectors on NX™ CPU Board. Verify Key alignment and firmly press board into place.



Page 2



NXP-DIM8

### **DIMMER ADDRESS SELECTION**

Each dimmer card has a selection switch marked S2 (see figure above) to set the dimmer number sequence in the panel. Regardless of where the card is installed in the panel, the S2 setting will determine the card's dimmer numbering as: 1 - 8, 9 - 16, 17 - 24, or 25 - 32.

## **NXP-DIM8 DIMMING CARD Configuration DIP Switches**

			Dimmer	MAC Sub-address range
ADD1	ADD2	ADD3	Numbers	(HEX)
OFF	OFF	OFF	1 - 8	D036 - D03D
ON	OFF	OFF	9 - 16	D03E - D045
OFF	ON	OFF	17 - 24	D046 - D04D
ON	ON	OFF	25 - 32	D04E - D055

#### DIMMING CHANNEL CONNECTIONS

To connect the low voltage dimming inputs, do the following:

- 1. Bring the low voltage wiring for the dimming circuits in through the knockouts in the low voltage wiring area. Circuits are software configurable through programming. Each dimming channel is capable of sinking 100mA.
- 2. Terminate the gray and purple wires from the dimming driver/ballast to the appropriate terminals using 16-18 AWG wire.