

pana_vp_PTFRW_FRX_FRZ_RW_RX_RZ_Series_v1_1_0_0

Command reference — **generated based on the Python file**

device/pana_vp_PTFRW_FRX_FRZ_RW_RX_RZ_Series_v1_1_0_0.py. This document was produced automatically by parsing the driver module (no vendor documentation was available for this device); it lists the control/status commands the module implements.

Generated 2026-07-17

Device information

Property	Value
Device type	projector
Models	PT-RW930, PT-RX110, PT-FRZ98C, PT-FRW93C, PT-FRX110C, PT-RZ770, PT-RW730, PT-FRZ78C, PT-FRW73C, PT-RZ660, PT-RW620, PT-FRZ67C, PT-FRW62C
Connection	com_type=Network, protocol=TCP, net_port=1024, service_port=0

Commands

Command	Set	Update	Allowed values / Parameters
AspectRatio	Yes	Yes	Auto, Normal, Wide, Native, Full, Horizontal Fit, Vertical Fit
AutoImage	Yes	-	-
ClosedCaption	Yes	Yes	Off, 1, 2, 3, 4
Focus	Yes	-	Slow +, Slow -, Normal +, Normal -, Fast +, Fast -
Freeze	Yes	Yes	On, Off
Input	Yes	Yes	-
Keypad	Yes	-	0, 1, 2, 3, 4, 5, 6, 7, 8, 9
LampUsage	-	Yes	Params: Lamp
LensShiftHorizontal	Yes	-	Slow +, Slow -, Normal +, Normal -, Fast +, Fast -
LensShiftVertical	Yes	-	Slow +, Slow -, Normal +, Normal -, Fast +, Fast -
MenuNavigation	Yes	-	Menu, Enter, Up, Down, Left, Right, Default, Function
OperationHours	-	Yes	-
PictureMode	Yes	Yes	Dynamic, Natural, Standard, Cinema, Graphic, Dicom Sim, User, REC709
Power	Yes	Yes	On, Off
Shutter	Yes	Yes	On, Off
Zoom	Yes	-	Slow +, Slow -, Normal +, Normal -, Fast +, Fast -

Command strings

Raw command / query strings sent to the device, extracted from each Set/Update method (control characters shown as Python escapes, e.g. `\r`).

SetAspectRatio

values: Auto→■AD{};VSE:0■, Normal→■AD{};VSE:1■, Wide→■AD{};VSE:2■, Native→■AD{};VSE:5■, Full→■AD{};VSE:6■, Horizontal Fit→■AD{};VSE:9■, Vertical Fit→■AD{};VSE:10■

SetClosedCaption

values: Off→■AD{};OCC:0■, 1→■AD{};OCC:1■, 2→■AD{};OCC:2■, 3→■AD{};OCC:3■, 4→■AD{};OCC:4■

SetFocus

values: Slow +→■AD{};VXX:LNSI4=+00000■, Slow -→■AD{};VXX:LNSI4=+00001■, Normal +→■AD{};VXX:LNSI4=+00100■, Normal -→■AD{};VXX:LNSI4=+00101■, Fast +→■AD{};VXX:LNSI4=+00200■, Fast -→■AD{};VXX:LNSI4=+00201■

SetFreeze

values: On→■AD{};OFZ:1■, Off→■AD{};OFZ:0■

SetKeypad

values: 0→■AD{};ONK:0■, 1→■AD{};ONK:1■, 2→■AD{};ONK:2■, 3→■AD{};ONK:3■, 4→■AD{};ONK:4■, 5→■AD{};ONK:5■, 6→■AD{};ONK:6■, 7→■AD{};ONK:7■, 8→■AD{};ONK:8■, 9→■AD{};ONK:9■

SetLensShiftHorizontal

values: Slow +→■AD{};VXX:LNSI2=+00000■, Slow -→■AD{};VXX:LNSI2=+00001■, Normal +→■AD{};VXX:LNSI2=+00100■, Normal -→■AD{};VXX:LNSI2=+00101■, Fast +→■AD{};VXX:LNSI2=+00200■, Fast -→■AD{};VXX:LNSI2=+00201■

SetLensShiftVertical

values: Slow +→■AD{};VXX:LNSI3=+00000■, Slow -→■AD{};VXX:LNSI3=+00001■, Normal +→■AD{};VXX:LNSI3=+00100■, Normal -→■AD{};VXX:LNSI3=+00101■, Fast +→■AD{};VXX:LNSI3=+00200■, Fast -→■AD{};VXX:LNSI3=+00201■

SetMenuNavigation

values: Menu→■AD{};OMN■, Enter→■AD{};OEN■, Up→■AD{};OCU■, Down→■AD{};OCD■, Left→■AD{};OCL■, Right→■AD{};OCR■, Default→■AD{};OST■, Function→■AD{};FC1■

SetPictureMode

values: Dynamic→■AD{};VPM:DYN■, Natural→■AD{};VPM:NAT■, Standard→■AD{};VPM:STD■, Cinema→■AD{};VPM:CIN■, Graphic→■AD{};VPM:GRA■, Dicom Sim→■AD{};VPM:DIC■, User→■AD{};VPM:USR■, REC709→■AD{};VPM:709■

SetPower

values: On→■AD{};PON■, Off→■AD{};POF■

SetShutter

values: On→■AD{};OSH:1■, Off→■AD{};OSH:0■

SetZoom

values: Slow +→■AD{};VXX:LNSI5=+00000■, Slow -→■AD{};VXX:LNSI5=+00001■, Normal +→■AD{};VXX:LNSI5=+00100■, Normal -→■AD{};VXX:LNSI5=+00101■, Fast +→■AD{};VXX:LNSI5=+00200■, Fast -→■AD{};VXX:LNSI5=+00201■