

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scripter Modules, refer to the "[Guide to Using Scripter Modules](#)" document.

Device Specifications

Device Type: Streaming Media
Manufacturer: Extron
Firmware Version: 1.00
Model(s): NAVigator

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scripter Version
3.16.0000-b013	2.19.0

Version History

Module Version	Date	Notes
1_0_1_4	3/17/2023	Added VideoWallPresetRecall status. Made improvements to USBDeviceTieStatus and InputSwitchtoWindow.
1_0_1_3	1/11/2022	Added Matchstring for DeviceNameDecoder and DeviceNameEncoder. Removed support for '0' value for InputSwitchtoWindow command. Updated communication sheet.
1_0_1_2	10/6/2021	Added CustomBorderVisibilityDecoder, CustomBorderDurationDecoder, CustomBorderColorDecoder, CustomOSDDecoder, CustomOSDEncoder, CustomOSDDurationEncoder, CustomOSDDurationDecoder, CustomOSDLocationEncoder, CustomOSDLocationDecoder, CustomOSDTextEncoder, CustomOSDTextDecoder, CustomClearOSDTextEncoder, CustomClearOSDTextDecoder, DeviceLocationDecoder, DeviceLocationEncoder, DeviceNameDecoder, DeviceNameEncoder, DeviceTagsDecoder, DeviceTagsEncoder, HotkeySequenceDetectionDecoder, InputPresetRecallDecoder, LLDPStatusOOBLAN,

Global Scripter Module Communication Sheet

		LLDPStatusNAVLAN, LLDPStatusDecoder, LLDPStatusEthExtDecoder, LLDPStatusEncoder, LLDPStatusEthExtEncoder, WindowMute
1_0_1_1	6/11/2020	Added InputSwitchtoWindow, USBDeviceTieStatus, USBMatrixTieCommand, and VideoWallPresetRecall.
1_0_1_0	4/3/2020	Removed AudioInputFormat, InputStream. Added support for AudioMute, HDCPInputStatus, HDCPOutputStatus, and VideoMute on the encoder and decoder. Add BitRateControl, DeviceConnectionStatusEncoder and DeviceConnectionStatusDecoder.
1_0_0_9	2/25/2020	Fixed comm sheet.
1_0_0_7	10/24/2019	Prevents SubscribeStatuss from calling the FeedBackHandler if the 'Value' returned from the device is the same.
1_0_0_5	9/26/2019	Updated OutputTieStatus feedback.
1_0_0_3	9/9/2019	Updated Audio Mute commands. Will only work with NAV FW 1.00.0002-b021 or later.
1_0_0_2	8/28/2019	Remove 'All' state from the qualifier Output.
1_0_0_1	8/20/2019	Fixed Volume and VideoMute ReadStatus. Cast qualifier to integer.
1_0_0_0	8/1/2019	Initial version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`

Supported Class and Example

EthernetClass

```
NAVigatorDevice = SPDevice('SPDeviceAlias') # Alias Name of NAVigator  
InterfaceName = ModuleName.SPIClass(NAVigatorDevice, 'NAVigator')
```

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command AudioMuteDecoder	Value 'On'	Value 'Off'	
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
Qualifier Key 'Type'	Qualifier Value 'HDMI'	Qualifier Value 'Analog'	Qualifier Value 'All'
# AudioMuteDecoder example InterfaceName.Set('AudioMuteDecoder', 'On', {'ID': 4096, 'Type': 'HDMI'})			
Command AudioMuteEncoder	Value 'On'	Value 'Off'	
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# AudioMuteEncoder example InterfaceName.Set('AudioMuteEncoder', 'On', {'ID': 4096})			
Command BitRateControl	Value 150 to 900		
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# BitRateControl example InterfaceName.Set('BitRateControl', 900, {'ID': 4096})			
Command CustomBorderVisibilityDe coder	Value 'Enabled'	Value 'Disabled'	
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# CustomBorderVisibilityDecoder example InterfaceName.Set('CustomBorderVisibilityDecoder', 'Enabled', {'ID': 4096})			
Command CustomBorderColorDecod er	Value 'Yellow'	Value 'Orange'	Value 'Red'
	'Blue'	'Green'	'Magenta'
	'Teal'	'White'	'Black'
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# CustomBorderColorDecoder example InterfaceName.Set('CustomBorderColorDecoder', 'Yellow', {'ID': 4096})			
Command CustomBorderDurationDe coder	Value 0 to 501		
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# CustomBorderDurationDecoder example InterfaceName.Set('CustomBorderDurationDecoder', 0, {'ID': 4096})			

Global Scriptor Module Communication Sheet

Command CustomOSDDecoder	Value 'On' 'Off'		
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# CustomOSDDecoder example InterfaceName.Set('CustomOSDDecoder', 'On', {'ID': 4096})			
Command CustomOSDEncoder	Value 'On' 'Off'		
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# CustomOSDEncoder example InterfaceName.Set('CustomOSDEncoder', 'On', {'ID': 4096})			
Command CustomOSDDurationDecoder	Value 0 to 501		
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# CustomOSDDurationDecoder example InterfaceName.Set('CustomOSDDurationDecoder', 0, {'ID': 4096})			
Command CustomOSDDurationEncoder	Value 0 to 501		
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# CustomOSDDurationEncoder example InterfaceName.Set('CustomOSDDurationEncoder', 0, {'ID': 4096})			
Command CustomOSDLocationDecoder	Value 'Top-Left' 'Bottom-Right'	Value 'Top-Right'	Value 'Bottom-Left'
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# CustomOSDLocationDecoder example InterfaceName.Set('CustomOSDLocationDecoder', 0, {'ID': 4096})			
Command CustomOSDLocationEncoder	Value 'Top-Left' 'Bottom-Right'	Value 'Top-Right'	Value 'Bottom-Left'
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# CustomOSDLocationEncoder example InterfaceName.Set('CustomOSDLocationEncoder', 0, {'ID': 4096})			
Command CustomOSDTextDecoder	Value String		
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
Qualifier Key 'Row'	Qualifier Value 1 to 2		
# CustomOSDTextDecoder example InterfaceName.Set('CustomOSDTextDecoder', 0, {'ID': 4096})			

Global Scripter Module Communication Sheet

Command CustomOSDTextEncoder	Value String
Qualifier Key 'ID'	Qualifier Value 1 to 4096
Qualifier Key 'Row'	Qualifier Value 1 to 2
# CustomOSDTextEncoder example InterfaceName.Set('CustomOSDTextEncoder', 0, {'ID': 4096})	
Command CustomClearOSDTextDecoder	Value None
Qualifier Key 'ID'	Qualifier Value 1 to 4096
Qualifier Key 'Row'	Qualifier Value 1 to 2
# CustomClearOSDTextDecoder example InterfaceName.Set('CustomClearOSDTextDecoder', 0, {'ID': 4096})	
Command CustomClearOSDTextEncoder	Value None
Qualifier Key 'ID'	Qualifier Value 1 to 4096
Qualifier Key 'Row'	Qualifier Value 1 to 2
# CustomClearOSDTextEncoder example InterfaceName.Set('CustomClearOSDTextEncoder', 0, {'ID': 4096})	
Command DeviceLocationDecoder	Value String
Qualifier Key 'ID'	Qualifier Value 1 to 4096
# DeviceLocationDecoder example InterfaceName.Set('DeviceLocationDecoder', 'Location', {'ID': 4096})	
Command DeviceLocationEncoder	Value String
Qualifier Key 'ID'	Qualifier Value 1 to 4096
# DeviceLocationEncoder example InterfaceName.Set('DeviceLocationEncoder', 'Location', {'ID': 4096})	
Command DeviceNameDecoder	Value String
Qualifier Key 'ID'	Qualifier Value 1 to 4096
# DeviceNameDecoder example InterfaceName.Set('DeviceNameDecoder', 'Name', {'ID': 4096})	
Command DeviceNameEncoder	Value String
Qualifier Key 'ID'	Qualifier Value 1 to 4096
# DeviceNameEncoder example InterfaceName.Set('DeviceNameEncoder', 'Name', {'ID': 4096})	

Command	Value		
DeviceTagsDecoder	String		
Qualifier Key	Qualifier Value		
'ID'	1 to 4096		
# DeviceTagsDecoder example InterfaceName.Set('DeviceTagsDecoder', 'Name', {'ID': 4096})			
Command	Value		
DeviceTagsEncoder	String		
Qualifier Key	Qualifier Value		
'ID'	1 to 4096		
# DeviceTagsEncoder example InterfaceName.Set('DeviceTagsEncoder', 'Name', {'ID': 4096})			
Command	Value	Value	
HDCPInputAuthorization	'On'	'Off'	
Qualifier Key	Qualifier Value		
'ID'	1 to 4096		
# HDCPInputAuthorization example InterfaceName.Set('HDCPInputAuthorization', 'On', {'ID': 4096})			
Command	Value		
InputPresetRecallDecoder	1 to 16		
Qualifier Key	Qualifier Value		
'ID'	1 to 4096		
# InputPresetRecallDecoder example InterfaceName.Set('InputPresetRecallDecoder', 1, {'ID': '4096'})			
Command	Value		
InputSwitchtoWindow	0 to 4096		
Qualifier Key	Qualifier Value		
'Canvas'	1 to 8		
Qualifier Key	Qualifier Value		
'Window'	1 to 64		
# InputSwitchtoWindow example InterfaceName.Set('InputSwitchtoWindow', 4096, {'Canvas': '8', 'Window': '64'})			
Command	Value		
MatrixTieCommand	None		
Qualifier Key	Qualifier Value		
'Input'	1 to 4096		
Qualifier Key	Qualifier Value		
'Output'	1 to 4096		
Qualifier Key	Qualifier Value	Qualifier Value	Qualifier Value
'Tie Type'	'Audio'	'Video'	'Audio/Video'
# MatrixTieCommand example InterfaceName.Set('MatrixTieCommand', None, {'Input': 4096, 'Output': 4096, 'Tie Type': 'Audio'})			
Command	Value		
RefreshMatrix	None		
# RefreshMatrix example InterfaceName.Set('RefreshMatrix', None, None)			

Global Scripter Module Communication Sheet

Command USBMatrixTieCommand	Value None		
Qualifier Key 'Device I/O Number'	Qualifier Value 1 to 4096		
Qualifier Key 'Device Type'	Qualifier Value 'Input'	Qualifier Value 'Output'	
Qualifier Key 'Host I/O Number'	Qualifier Value 0 to 4096		
Qualifier Key 'Host Type'	Qualifier Value 'Input'	Qualifier Value 'Output'	
# USBMatrixTieCommand example InterfaceName.Set('USBMatrixTieCommand', None, {'Device I/O Number': 4096, 'Device Type': 'Output', 'Host I/O Number': 4096, 'Host Type': 'Input'})			
Command VideoMuteDecoder	Value 'On'	Value 'Video and Sync'	Value 'Off'
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# VideoMuteDecoder example InterfaceName.Set('VideoMuteDecoder', 'On', {'ID': 4096})			
Command VideoMuteEncoder	Value 'On'	Value 'Video and Sync'	Value 'Off'
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# VideoMuteEncoder example InterfaceName.Set('VideoMuteEncoder', 'On', {'ID': 4096})			
Command VideoWallPresetRecall	Value 1 to 8		
Qualifier Key 'Canvas'	Qualifier Value 1 to 8		
# VideoWallPresetRecall example InterfaceName.Set('VideoWallPresetRecall', '8', {'Canvas': '8'})			
Command Volume	Value 0 to 100 in steps of 1		
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# Volume example InterfaceName.Set('Volume', 100, {'ID': 4096})			

Status Available

For all commands except for HDCPInputAuthorization, HDCPInputStatusDecoder, HDCPInputStatusEncoder, HDCPOutputStatusDecoder, HDCPOutputStatusEncoder, InputSignalStatus. Update should be called only once since the command's status will be updated automatically as the device's status changes. ConnectionStatus, OutputTieStatus do not support the Update function. ConnectionStatus is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'},
```

```
FeedbackHandler)
```

FeedbackHandler will be called only when the specified qualifier gets a new status.

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command AudioMuteDecoder	Value 'On'	Value 'Off'
Qualifier Key 'ID'	Qualifier Value 1 to 4096	
Qualifier Key 'Type'	Qualifier Value 'HDMI'	Qualifier Value 'Analog'
Qualifier Value 'All'		
# AudioMuteDecoder example InterfaceName.Update('AudioMuteDecoder', {'ID': 4096, 'Type': 'HDMI'}) Value = InterfaceName.ReadStatus('AudioMuteDecoder', {'ID': 4096, 'Type': 'HDMI'}) InterfaceName.SubscribeStatus('AudioMuteDecoder', None, FeedbackHandler)		
Command AudioMuteEncoder	Value 'On'	Value 'Off'
Qualifier Key 'ID'	Qualifier Value 1 to 4096	
# AudioMuteEncoder example InterfaceName.Update('AudioMuteEncoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('AudioMuteEncoder', {'ID': 4096}) InterfaceName.SubscribeStatus('AudioMuteEncoder', None, FeedbackHandler)		
Command BitRateControl	Value 150-900	
Qualifier Key 'ID'	Qualifier Value 1 to 4096	
# BitRateControl example InterfaceName.Update('BitRateControl', {'ID': 4096}) Value = InterfaceName.ReadStatus('BitRateControl', {'ID': 4096}) InterfaceName.SubscribeStatus('BitRateControl', None, FeedbackHandler)		

Global Scriptor Module Communication Sheet

Command CustomBorderVisibilityDecoder	Value 'Enabled'	Value 'Disabled'	
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# CustomBorderVisibilityDecoder example InterfaceName.Update('CustomBorderVisibilityDecoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('CustomBorderVisibilityDecoder', {'ID': 4096}) InterfaceName.SubscribeStatus('CustomBorderVisibilityDecoder', None, FeedbackHandler)			
Command CustomBorderColorDecoder	Value 'Yellow' 'Blue' 'Teal'	Value 'Orange' 'Green' 'White'	Value 'Red' 'Magenta' 'Black'
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# CustomBorderColorDecoder example InterfaceName.Update('CustomBorderColorDecoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('CustomBorderColorDecoder', {'ID': 4096}) InterfaceName.SubscribeStatus('CustomBorderColorDecoder', None, FeedbackHandler)			
Command CustomBorderDurationDecoder	Value 0 to 501		
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# CustomBorderDurationDecoder example InterfaceName.Update('CustomBorderDurationDecoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('CustomBorderDurationDecoder', {'ID': 4096}) InterfaceName.SubscribeStatus('CustomBorderDurationDecoder', None, FeedbackHandler)			
Command CustomOSDDecoder	Value 'On'	Value 'Off'	
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# CustomOSDDecoder example InterfaceName.Update('CustomOSDDecoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('CustomOSDDecoder', {'ID': 4096}) InterfaceName.SubscribeStatus('CustomOSDDecoder', None, FeedbackHandler)			
Command CustomOSDEncoder	Value 'On'	Value 'Off'	
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# CustomOSDEncoder example InterfaceName.Update('CustomOSDEncoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('CustomOSDEncoder', {'ID': 4096}) InterfaceName.SubscribeStatus('CustomOSDEncoder', None, FeedbackHandler)			
Command CustomOSDDurationDecoder	Value 0 to 501		
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# CustomOSDDurationDecoder example InterfaceName.Update('CustomOSDDurationDecoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('CustomOSDDurationDecoder', {'ID': 4096}) InterfaceName.SubscribeStatus('CustomOSDDurationDecoder', None, FeedbackHandler)			

Global Scriptor Module Communication Sheet

Command CustomOSDDurationEncoder	Value 0 to 501		
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# CustomOSDDurationEncoder example InterfaceName.Update('CustomOSDDurationEncoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('CustomOSDDurationEncoder', {'ID': 4096}) InterfaceName.SubscribeStatus('CustomOSDDurationEncoder', None, FeedbackHandler)			
Command CustomOSDLocationDecoder	Value 'Top-Left' 'Bottom-Right'	Value 'Top-Right'	Value 'Bottom-Left'
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# CustomOSDLocationDecoder example InterfaceName.Update('CustomOSDLocationDecoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('CustomOSDLocationDecoder', {'ID': 4096}) InterfaceName.SubscribeStatus('CustomOSDLocationDecoder', None, FeedbackHandler)			
Command CustomOSDLocationEncoder	Value 'Top-Left' 'Bottom-Right'	Value 'Top-Right'	Value 'Bottom-Left'
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# CustomOSDLocationionEncoder example InterfaceName.Update('CustomOSDLocationEncoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('CustomOSDLocationEncoder', {'ID': 4096}) InterfaceName.SubscribeStatus('CustomOSDLocationEncoder', None, FeedbackHandler)			
Command CustomOSDTextDecoder	Value String		
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
Qualifier Key 'Row'	Qualifier Value 1 to 2		
# CustomOSDTextDecoder example InterfaceName.Update('CustomOSDTextDecoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('CustomOSDTextDecoder', {'ID': 4096}) InterfaceName.SubscribeStatus('CustomOSDTextDecoder', None, FeedbackHandler)			
Command CustomOSDTextEncoder	Value String		
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
Qualifier Key 'Row'	Qualifier Value 1 to 2		
# CustomOSDTextEncoder example InterfaceName.Update('CustomOSDTextEncoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('CustomOSDTextEncoder', {'ID': 4096}) InterfaceName.SubscribeStatus('CustomOSDTextEncoder', None, FeedbackHandler)			
Command ConnectionStatus	Value 'Connected'	Value 'Disconnected'	
Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)			

Global Scripser Module Communication Sheet

Command DeviceConnectionStatusDecoder	Value 'Connected'	Value 'Disconnected'
Qualifier Key 'ID'	Qualifier Value 1 to 4096	
Value = InterfaceName.ReadStatus('DeviceConnectionStatusDecoder') InterfaceName.SubscribeStatus('DeviceConnectionStatusDecoder', None, FeedbackHandler)		
Command DeviceConnectionStatusEncoder	Value 'Connected'	Value 'Disconnected'
Qualifier Key 'ID'	Qualifier Value 1 to 4096	
Value = InterfaceName.ReadStatus('DeviceConnectionStatusEncoder') InterfaceName.SubscribeStatus('DeviceConnectionStatusEncoder', None, FeedbackHandler)		
Command DeviceLocationDecoder	Value String	
Qualifier Key 'ID'	Qualifier Value 1 to 4096	
# DeviceLocationDecoder example InterfaceName.Update('DeviceLocationDecoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('DeviceLocationDecoder', {'ID': 4096}) InterfaceName.SubscribeStatus('DeviceLocationDecoder', None, FeedbackHandler)		
Command DeviceLocationEncoder	Value String	
Qualifier Key 'ID'	Qualifier Value 1 to 4096	
# DeviceLocationEncoder example InterfaceName.Update('DeviceLocationEncoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('DeviceLocationEncoder', {'ID': 4096}) InterfaceName.SubscribeStatus('DeviceLocationEncoder', None, FeedbackHandler)		
Command DeviceNameDecoder	Value String	
Qualifier Key 'ID'	Qualifier Value 1 to 4096	
# DeviceNameDecoder example InterfaceName.Update('DeviceNameDecoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('DeviceNameDecoder', {'ID': 4096}) InterfaceName.SubscribeStatus('DeviceNameDecoder', None, FeedbackHandler)		
Command DeviceNameEncoder	Value String	
Qualifier Key 'ID'	Qualifier Value 1 to 4096	
# DeviceNameEncoder example InterfaceName.Update('DeviceNameEncoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('DeviceNameEncoder', {'ID': 4096}) InterfaceName.SubscribeStatus('DeviceNameEncoder', None, FeedbackHandler)		
Command DeviceTagsDecoder	Value String	
Qualifier Key 'ID'	Qualifier Value 1 to 4096	
# DeviceTagsDecoder example InterfaceName.Update('DeviceTagsDecoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('DeviceTagsDecoder', {'ID': 4096}) InterfaceName.SubscribeStatus('DeviceTagsDecoder', None, FeedbackHandler)		

Global Scriptor Module Communication Sheet

Command DeviceTagsEncoder	Value String		
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# DeviceTagsEncoder example InterfaceName.Update('DeviceTagsEncoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('DeviceTagsEncoder', {'ID': 4096}) InterfaceName.SubscribeStatus('DeviceTagsEncoder', None, FeedbackHandler)			
Command HDCPInputAuthorization	Value 'On'	Value 'Off'	
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# HDCPInputAuthorization example InterfaceName.Update('HDCPInputAuthorization', {'ID': 4096}) Value = InterfaceName.ReadStatus('HDCPInputAuthorization', {'ID': 4096}) InterfaceName.SubscribeStatus('HDCPInputAuthorization', None, FeedbackHandler)			
Command HDCPInputStatusDecoder	Value 'No Device'	Value 'Non HDCP Device'	Value 'HDCP Device'
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# HDCPInputStatusDecoder example InterfaceName.Update('HDCPInputStatusDecoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('HDCPInputStatusDecoder', {'ID': 4096}) InterfaceName.SubscribeStatus('HDCPInputStatusDecoder', None, FeedbackHandler)			
Command HDCPInputStatusEncoder	Value 'No Device'	Value 'Non HDCP Device'	Value 'HDCP Device'
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# HDCPInputStatusEncoder example InterfaceName.Update('HDCPInputStatusEncoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('HDCPInputStatusEncoder', {'ID': 4096}) InterfaceName.SubscribeStatus('HDCPInputStatusEncoder', None, FeedbackHandler)			
Command HDCPOutputStatusDecod er	Value 'No Device'	Value 'Non HDCP Device'	Value 'HDCP Device'
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# HDCPOutputStatusDecoder example InterfaceName.Update('HDCPOutputStatusDecoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('HDCPOutputStatusDecoder', {'ID': 4096}) InterfaceName.SubscribeStatus('HDCPOutputStatusDecoder', None, FeedbackHandler)			
Command HDCPOutputStatusEncode r	Value 'No Device'	Value 'Non HDCP Device'	Value 'HDCP Device'
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# HDCPOutputStatusEncoder example InterfaceName.Update('HDCPOutputStatusEncoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('HDCPOutputStatusEncoder', {'ID': 4096}) InterfaceName.SubscribeStatus('HDCPOutputStatusEncoder', None, FeedbackHandler)			

Global Scriptor Module Communication Sheet

Command HotkeySequenceDetectionDecoder	Value 1 to 32		
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
Qualifier Key 'Modifier'	Qualifier Value 'Ctrl, Ctrl'	Qualifier Value 'Ctrl, Shift'	
# HotkeySequenceDetectionDecoder example Value = InterfaceName.ReadStatus('HotkeySequenceDetectionDecoder', {'ID': 4096}) InterfaceName.SubscribeStatus('HotkeySequenceDetectionDecoder', None, FeedbackHandler)			
Command InputSignalStatus	Value 'Active'	Value 'Not Active'	
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
# InputSignalStatus example InterfaceName.Update('InputSignalStatus', {'ID': 4096}) Value = InterfaceName.ReadStatus('InputSignalStatus', {'ID': 4096}) InterfaceName.SubscribeStatus('InputSignalStatus', None, FeedbackHandler)			
Command InputSwitchtoWindow	Value 0 to 4096		
Qualifier Key 'Canvas'	Qualifier Value 1 to 8		
Qualifier Key 'Window'	Qualifier Value 1 to 64		
# InputSwitchtoWindow example InterfaceName.Update('InputSwitchtoWindow', {'Canvas': '8', 'Window': '64'}) Value = InterfaceName.ReadStatus('InputSwitchtoWindow', {'Canvas': '8', 'Window': '64'}) InterfaceName.SubscribeStatus('InputSwitchtoWindow', None, FeedbackHandler)			
Command LLDPStatusDecoder	Value String		
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
Qualifier Key 'Data Type'	Qualifier Value 'System Name' 'System Description' 'Time to Live'	Qualifier Value 'Management Address' 'VLAN ID' 'Port Description'	Qualifier Value 'Port ID' 'Chassis ID' 'System Capabilities'
# LLDPStatusDecoder example InterfaceName.Update('LLDPStatusDecoder', {'ID': 4096, 'Data Type': 'System Name'}) Value = InterfaceName.ReadStatus('LLDPStatusDecoder', {'ID': 4096, 'Data Type': 'System Name'}) InterfaceName.SubscribeStatus('LLDPStatusDecoder', None, FeedbackHandler)			

Global Scriptor Module Communication Sheet

Command LLDPStatusEthExtDecoder	Value String		
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
Qualifier Key 'Data Type'	Qualifier Value 'System Name' 'System Description' 'Time to Live'	Qualifier Value 'Management Address' 'VLAN ID' 'Port Description'	Qualifier Value 'Port ID' 'Chassis ID' 'System Capabilities'
<pre># LLDPStatusEthExtDecoder example InterfaceName.Update('LLDPStatusEthExtDecoder', {'ID': 4096, 'Data Type': 'System Name'}) Value = InterfaceName.ReadStatus('LLDPStatusEthExtDecoder', {'ID': 4096, 'Data Type': 'System Name'}) InterfaceName.SubscribeStatus('LLDPStatusEthExtDecoder', None, FeedbackHandler)</pre>			
Command LLDPStatusEncoder	Value String		
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
Qualifier Key 'Data Type'	Qualifier Value 'System Name' 'System Description' 'Time to Live'	Qualifier Value 'Management Address' 'VLAN ID' 'Port Description'	Qualifier Value 'Port ID' 'Chassis ID' 'System Capabilities'
<pre># LLDPStatusEncoder example InterfaceName.Update('LLDPStatusEncoder', {'ID': 4096, 'Data Type': 'System Name'}) Value = InterfaceName.ReadStatus('LLDPStatusEncoder', {'ID': 4096, 'Data Type': 'System Name'}) InterfaceName.SubscribeStatus('LLDPStatusEncoder', None, FeedbackHandler)</pre>			
Command LLDPStatusEthExtEncoder	Value String		
Qualifier Key 'ID'	Qualifier Value 1 to 4096		
Qualifier Key 'Data Type'	Qualifier Value 'System Name' 'System Description' 'Time to Live'	Qualifier Value 'Management Address' 'VLAN ID' 'Port Description'	Qualifier Value 'Port ID' 'Chassis ID' 'System Capabilities'
<pre># LLDPStatusEthExtEncoder example InterfaceName.Update('LLDPStatusEthExtEncoder', {'ID': 4096, 'Data Type': 'System Name'}) Value = InterfaceName.ReadStatus('LLDPStatusEthExtEncoder', {'ID': 4096, 'Data Type': 'System Name'}) InterfaceName.SubscribeStatus('LLDPStatusEthExtEncoder', None, FeedbackHandler)</pre>			
Command LLDPStatusNAVLAN	Value String		
Qualifier Key 'Data Type'	Qualifier Value 'System Name' 'System Description' 'Time to Live'	Qualifier Value 'Management Address' 'VLAN ID' 'Port Description'	Qualifier Value 'Port ID' 'Chassis ID' 'System Capabilities'
<pre># LLDPStatusNAVLAN example InterfaceName.Update('LLDPStatusNAVLAN', {'Data Type': 'System Name'}) Value = InterfaceName.ReadStatus('LLDPStatusNAVLAN', {'Data Type': 'System Name'}) InterfaceName.SubscribeStatus('LLDPStatusNAVLAN', None, FeedbackHandler)</pre>			

Global Scripter Module Communication Sheet

Command	Value		
LLDPStatusOOBLAN	String		
Qualifier Key	Qualifier Value	Qualifier Value	Qualifier Value
'Data Type'	'System Name'	'Management Address'	'Port ID'
	'System Description'	'VLAN ID'	'Chassis ID'
	'Time to Live'	'Port Description'	'System Capabilities'
# LLDPStatusOOBLAN example InterfaceName.Update('LLDPStatusOOBLAN', {'Data Type': 'System Name'}) Value = InterfaceName.ReadStatus('LLDPStatusOOBLAN', {'Data Type': 'System Name'}) InterfaceName.SubscribeStatus('LLDPStatusOOBLAN', None, FeedbackHandler)			
Command	Value		
OutputTieStatus	0 to 4096		
Qualifier Key	Qualifier Value		
'Output'	1 to 4096		
Qualifier Key	Qualifier Value	Qualifier Value	Qualifier Value
'Tie Type'	'Audio'	'Video'	'Audio/Video'
# OutputTieStatus example Value = InterfaceName.ReadStatus('OutputTieStatus', {'Output': 4096, 'Tie Type': 'Audio'}) InterfaceName.SubscribeStatus('OutputTieStatus', None, FeedbackHandler)			
Command	Value		
USBDeviceTieStatus ¹	0 to 4096		
Qualifier Key	Qualifier Value		
'Device I/O Number'	1 to 4096		
Qualifier Key	Qualifier Value	Qualifier Value	
'Device Type'	'Input'	'Output'	
Qualifier Key	Qualifier Value	Qualifier Value	
'Host Type'	'Input'	'Output'	
# USBDeviceTieStatus example Value = InterfaceName.ReadStatus('USBDeviceTieStatus', {'Device I/O Number': 4096, 'Device Type': 'Output', 'Host Type': 'Input'}) InterfaceName.SubscribeStatus('USBDeviceTieStatus', None, FeedbackHandler)			
Command	Value	Value	Value
VideoMuteDecoder	'On'	'Video and Sync'	'Off'
Qualifier Key	Qualifier Value		
'ID'	1 to 4096		
# VideoMuteDecoder example InterfaceName.Update('VideoMuteDecoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('VideoMuteDecoder', {'ID': 4096}) InterfaceName.SubscribeStatus('VideoMuteDecoder', None, FeedbackHandler)			
Command	Value	Value	Value
VideoMuteEncoder	'On'	'Video and Sync'	'Off'
Qualifier Key	Qualifier Value		
'ID'	1 to 4096		
# VideoMuteEncoder example InterfaceName.Update('VideoMuteEncoder', {'ID': 4096}) Value = InterfaceName.ReadStatus('VideoMuteEncoder', {'ID': 4096}) InterfaceName.SubscribeStatus('VideoMuteEncoder', None, FeedbackHandler)			
Command	Value		
PartNumber	None		
# PartNumber example InterfaceName.Update('PartNumber') Value = InterfaceName.ReadStatus('PartNumber', None) InterfaceName.SubscribeStatus('PartNumber', None, FeedbackHandler)			
Command	Value		

Global Scriptor Module Communication Sheet

VideoWallPresetRecall	1 to 8
Qualifier Key 'Canvas'	Qualifier Value 1 to 8
<pre># VideoWallPresetRecall example InterfaceName.Update('VideoWallPresetRecall', {'Canvas': 8}) Value = InterfaceName.ReadStatus('VideoWallPresetRecall', {'Canvas': 8}) InterfaceName.SubscribeStatus('VideoWallPresetRecall', None, FeedbackHandler)</pre>	
Command Volume	Value 0 to 100 in steps of 1
Qualifier Key 'ID'	Qualifier Value 1 to 4096
<pre># Volume example InterfaceName.Update('Volume', {'ID': 4096}) Value = InterfaceName.ReadStatus('Volume', {'ID': 4096}) InterfaceName.SubscribeStatus('Volume', None, FeedbackHandler)</pre>	

¹ A USB Host can be configured to be an Input (Encoder) or Output (Decoder) and the Host Type should match this configuration. A USB Device can be configured to be an Input (Encoder) or Output (Decoder) and the Device Type should match this configuration. The Device I/O Number is the ID of the Device. The Value is the ID of the Host.

Network communication

When configuring the SPInterface module, be sure device settings match those of the Global Scripter ethernet interface.

Port Type: SPInterface

SPInterface Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device