

V E N D A

Vend-a-Shu


App Walkthrough

A step-by-step guide to storing, photographing, vending, and returning your shoes with your automated Vend-a-Shu storage unit.

What's inside

- Step 1: Get Set Up — Onboarding
- Step 2: Connect — Connect to Database
- Step 3: Sign In — Select Your User
- Step 4: Home Base — Home Screen
- Step 5: Add Shoes — Photo Studio
- Step 6: Vend Shoes — Vend Shoes
- Step 7: Return Shoes — Return Shoes

Onboarding



When you open Vend-a-Shu for the first time, a short onboarding tour introduces the app. The first screen reminds you to connect to the same Wi-Fi network as your VAS (Vend-a-Shu) unit — the app talks to the unit over your home network. Tap Next to move through the tour.

STEP 2 — CONNECT

Connect to Database



Connect to Database



● VAS database online

IP Address (optional — auto-connected)

Port (optional — auto-connected)

Connect


Where can I find my IP?

When running against a Raspberry Pi VAS unit, enter its IP and port. Here, the app is already connected to the built-in VAS database, so you can just tap Connect.

This screen links the app to your VAS unit. If you are running against a Raspberry Pi VAS unit, enter its IP address and port. When using the built-in VAS database (as shown here — note the green “VAS database online” badge), both fields are optional: just tap Connect.

STEP 3 — SIGN IN

Select Your User




The screenshot shows a mobile app login screen. At the top left is the logo for 'VENDA SHU', which includes a red high-heeled shoe icon. Below the logo, the text 'Hi! Welcome' is displayed in a large, bold, dark blue font. Underneath this, a smaller line of text says 'I am waiting for you, please enter your details'. There is a white dropdown menu with the text 'Select User' and a small downward arrow. Below the dropdown is a toggle switch labeled 'Remember me', which is currently turned on (orange). At the bottom of the screen is a large orange button with the text 'Go to my VAS' in white.

Pick your name from the Select User dropdown so shoes are stored under the right owner. Turn on “Remember me” to skip this screen next time, then tap “Go to my VAS” to enter the app.

STEP 4 — HOME BASE


Home Screen



Your dashboard at a glance: how many shoes are stored and how many are currently out of their bins. From here you can Add Shoes (store a new pair), Vend Shoes (have the unit eject a pair), Return Shoes (put a pair back), or open Options. Use “Switch User” at the bottom to change owners, and the “?” button for help.

STEP 5 — ADD SHOES


Photo Studio



Adding a pair starts in the Photo Studio. Take a photo with your camera or pick one from your library — the app automatically cuts out the background so your shoes look studio-ready. Then choose a backdrop: clean White or one of eight premade scenes (Studio Grey, Warm Wood, Marble, Sunset Orange, Concrete Loft, Blush Pink, Midnight Navy, Botanical). You can also skip the photo entirely with “Continue without photo.” Next, fill in the shoe details (type, color, designer, season, material) and the app assigns the pair to a bin in your unit.

STEP 6 — VEND SHOES


Vend Shoes



Browse everything stored in your unit — each pair shows its photo (or an icon if no photo was taken). Search by type, color, or designer, or narrow down with the Season, Color, Brand, and Material filters. Tap a pair, confirm, and the VAS unit ejects the bin holding your shoes and lights it up.

STEP 7 — RETURN SHOES

Return Shoes



Anything you vended shows up here until it goes back. Tap the pair you are returning, and the unit opens the correct bin so the shoes always land in their assigned home. When nothing is out, you will see this empty state. That completes the cycle: add, vend, return.