REMOTE SOURCE

RS406PC-X

Six-Circuit-channel Wireless Intelligent Receiving Receiver

I.Main Technical Param

- **Voltage:** DC12V DC24V(optional)
- **Working temperature:**-40℃-+80℃
- **Frequency:** 315MHz, 433MHz(optional)
- **Sensitivity:**⩽-105dBm
- **Contact current:**⩽10A
- **Static current:** ⩽8mA
- **Receiver capacity:**30(learning code & fixed code)
- **Size:** 113x80x32mm

II. Output Mode

A. Signal momentary — "Learning" by button 1
B. Signal toggle — "Learning" by button 2
C. Signal latch — "Learning" by button 3
D.3-circuit-channel momentary and 3-circuit-channel toggle— "Learning" by button 4


III. Method & Steps for Learning


A. Press "Learning" button, release it until LED light flickers, Learning light goes out again and then Receiver in learning status this moment.
B. Press any corresponding button on Remote control. If Learning is accomplished, learning light on Receiver will flickers 5 times quickly and then exit Learning status. If more than 32s, still no Learning, Receiver will exit Learning status automatically.

IV. Eliminate stored Information

Press "Learning" button for 8s, learning light turns on and then goes out again, that indicates all stored information has been eliminated.

V. Wiring Diagram





IV.Wring Diagram

