REOLINK TECHNOLOGY PTE.LTD.
3 TAI SENG AVENUE,#07-31,TAI SENG EXCHANGE,SINGAPORE 536465

FR
Cet appareil, ses accessoires et cordons se recyclent
À DÉPOSER EN MAGASIN
OU
À DÉPOSER EN DÉCHÈTERIE
Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

RECICLA
Al Azul


PAP 22
Raccolta Carta

58.03.010.0152

Reolink

TrackFlex WiFi

Operational Instructions



@ReolinkTech https://reolink.com


EN
Item No. : W762


EN

Contents


01 What's in the Box 02
02 Device Overview 03
03 Set Up the Camera 05
04 Maintenance Guidelines 09
05 Install the Camera 10
06 Specifications 17
07 Important Safety Instructions 17
08 Troubleshooting 18
09 Legal Disclaimer 19
10 Notification of Compliance 20

01 What's in the Box


Camera


Mounting Bracket


Mounting Template


Power Adapter


Pack of Screws




Surveillance Sticker




Operational Instructions

NOTE:
Compatible with the Reolink junction box (sold separately)
For the latest compatibility list, please visit:
https://support.reolink.com/c/junction-box/

What You Also Need *Not Included



#2 PH Screwdriver




Power Drill



Ladder
(If Necessary)

02 Device Overview

1. Mounting Bracket
2. Speaker
3. PIR Sensors
4. Spotlight & IR LEDs
5. Indicator Light
6. Microphone
7. Lens
8. microSD Card Cover
9. Release Button
10. Power Port
11. microSD Card Slot
12. Reset Button
    * Press and hold for 10 seconds to restore factory settings.



03 Set Up the Camera

Step 1. Download the Reolink App or Client

• **On Smartphone**


Download on the App Store

GET IT ON Google Play

• **On PC**

Download the Reolink Client: Go to https://reolink.com > Support > Download Center > App & Client.

Step 2. Power on the Camera




NOTE:
When powered on, the status light flashes blue.

Status Indicator Light:

- **Solid Blue:** The device is powered on and connected to the network.
- **Flashing Blue:**
  A. The device is powering on and initializing.
  B. The device has completed initialization, but a network error is detected.
- **No Light:** The device is not powered.

Step 3. Initialize the Camera


Tap the "+" button in the top corner, scan the camera's QR code, and follow the on-screen instructions to complete the setup.



NOTE:
- This camera uses Bluetooth for the initial network setup. Ensure your phone's Bluetooth is turned on before proceeding.
- If using the Reolink Client, click "Add Device" and enter the camera's UID (found below the QR code).
- After successful initialization, the status light will change from flashing blue to solid blue.

Step 4. Insert the microSD Card (Optional)

Open the slot cover, insert the microSD card (not provided), and securely put the cover back on.



NOTE:
For reliable video storage, we recommend using a Class 10 microSD card (up to 512GB).

04 Maintenance Guidelines

Tip 1. Mounting for Optimal Image Quality

Ensure both the camera location and the monitored area are evenly lit.

- **Avoid pointing at light sources or directly at windows to prevent flare and overexposure.**

- **Avoid installing in deep shade; position the camera to face a well-lit zone.**

Tip 2. Protecting Your Camera

- **Keep the power port dry and free from dirt/debris to maintain its resistance.**

Tip 3. Regular Maintenance


- **Periodically clean the lens gently with a soft cloth.**

05 Install the Camera


Step 1. Choose a Mounting Location

Install the camera 2–3 meters (7–10 feet)* high for optimal PIR detection performance.

**The PIR sensor detects motion within a range of 2 to 10 meters and a 270° coverage angle.*




For optimal detection, install the camera at an angle where motion moves laterally across the PIR sensor's field of view.




Step 2. Choose a Mounting Method


A Ceiling Mounting



B Wall Mounting




C Corner Mounting




NOTE:
Corner bracket sold separately.

Cable Routing Methods


A




B



C



D




Step 3. Secure the Mounting Bracket


Drill holes as indicated in the mounting template. Use included long screws to secure the bracket.

NOTE:
Use the included drywall anchors if needed.

A Wall Mounting




B Ceiling Mounting



Step 4. Secure the Camera


Select a cable routing method based on your installation.
Align the camera with the bracket holes and push until it clicks into place.



NOTE:
To detach, press the release buttons on both sides of the bracket and slide the camera out.

Step 5. Adjust the Camera Angles

You can remotely pan and tilt the camera via the Reolink App or Client. Please peel off the PIR protective film before use.



06 Specifications

Operating Temperature: -10°C ~+55°C (14°F~131°F)
Operating Humidity: 10%~90%
Weatherproof IP66
Weight: 725g

For additional specifications, please visit https://reolink.com/.

07 Important Safety Instructions

Please read the instructions carefully before using the device.

1. Replace only with the same or equivalent type of accessories recommended by Reolink.
2. Do not use the device in an environment that exceeds the recommended temperature range.
3. Do not use the device in an environment that exceeds the recommended humidity range.
4. Do not attempt to disassemble, repair, or alter the device by yourself.
5. Always follow the local safety laws and regulations when using the device.
6. The device contains (or comes with) small components, small plastic elements, and other small parts that may cause choking hazards. Keep the device and its accessories out of reach of children. Consult a physician immediately if small parts are swallowed.
7. The device contains (or comes with) cables or cords that may cause strangulation hazards. Keep the device and its accessories out of reach of children.

08 Troubleshooting

Camera Is Not Powering On

If your camera is not powering on, please try the following solutions:

• Plug the camera into another outlet.
• Use another 12V/1A power adapter to power up the camera.

If these won't work, contact Reolink Support https://support.reolink.com/

Wi-Fi Connection Failed During initial setup

If the camera failed to connect to Wi-Fi during setup, please try:

- Please ensure you have entered the correct Wi-Fi password.
- Put your camera close to your router to ensure a strong Wi-Fi signal.
- Change the encryption method of the WiFi network to WPA2-PSK/WPA-PSK (safer encryption) on your router interface.
- Change your Wi-Fi SSID or password and make sure that SSID is within 31 characters and password is within 64 characters.
- Set your password using only the characters on the keyboard.

If these won't work, contact Reolink Support https://support.reolink.com/

Camera Doesn’t Work Properly When Added to the Reolink NVR or Home Hub

If your Reolink camera isn’t working properly after being added to an NVR or Home Hub, please make sure the firmware on your camera, NVR, and Hub is updated to the latest version. If the issue continues after updating, contact Reolink Support at https://support.reolink.com/.

09 Legal Disclaimer

To the maximum extent permitted by applicable law, this document and the product described, with its hardware, software, firmware, and services, are delivered on an "as-is" and "as-available" basis, with all faults and without warranty of any kind. Reolink disclaims all warranties, express or implied, including but not limited to, warranties of merchantability, satisfactory quality, fitness for a particular purpose, accuracy, and non-infringement of third-party rights. In no event will Reolink, its directors, officers, employees, or agents be liable to you for any special, consequential, incidental or indirect damages, including but not limited to damages for loss of business profits, business interruption, or loss of data or documentation, in connection with the use of this product, even if Reolink has been advised of the possibility of such damages.

To the extent permitted by applicable law, your use of the Reolink products and services is at your sole risk and you assume all risks associated with internet access. Reolink does not take any responsibilities for abnormal operation, privacy leakage or other damages resulting from cyber attacks, hacker attacks, virus inspections, or other internet security risks. However, Reolink will provide timely technical support if required.

The laws and regulations related to this product vary by jurisdiction. Please check all relevant laws and regulations in your jurisdiction before using this product to ensure that your use conforms to the applicable law and regulation. During the use of the product, you must comply with relevant local laws and regulations. Reolink is not responsible for any illegal or improper use and its consequences. Reolink is not liable in the event that this product is used with illegitimate purposes, such as third-party rights infringement, medical treatment, safety equipment, or other situations where the product failure could lead to death or personal injury, or for weapons of mass destruction, chemical and biological weapons, nuclear explosion, and any unsafe nuclear energy uses or anti-humanity purposes. In the event of any conflicts between this manual and the applicable law, the latter prevails.

10 Notification of Compliance

SIMPLIFIED EU AND UK DECLARATION OF CONFORMITY

Hereby, REOLINK TECHNOLOGY PTE.LTD. declares that the radio equipment type [refer to the cover of the Operational Instructions] is in compliance with Directive 2014/53/EU.The full text of the EU and UK declaration of conformity is available at the following internet address:
https://reolink.com/certification-compliance/

RF exposure information: The Maximum Permissible Exposure (MPE) level has been calculated based on a distance of 20cm between the device and the human body. To maintain compliance with RF exposure requirement, use product that maintain a 20cm distance between the device

and human body.

Hereby, REOLINK TECHNOLOGY PTE.LTD. declares that this device is in compliance with Cyber Security (Security Standards for Smart Devices) Rules 2025. For the Statement of Compliance, visit the Web site https://reolink.com/certification-compliance/

Wi-Fi Operating Frequency

Operating Frequency :
2412~2472MHz RF Power:≤20dBm(EIRP)
5150~5250MHz RF Power:≤23dBm(EIRP)
5250~5350MHz RF Power:≤23dBm(EIRP)
5470~5725MHz RF Power:≤23dBm(EIRP)
5725~5875MHz RF Power:≤14dBm(EIRP)

Bluetooth operating Frequency

OPERATING FREQUENCY :
2402~2480MHz RF Power:≤10dBm(EIRP)



The functions of Wireless Access Systems including Radio Local Area Networks(WAS/RLANs) within the band 5150-5350 MHz for this device are restricted to indoor use only within all European Union countries (BE/BG/CZ/DK/DE/EE/IE/EL/ES/FR/HR/IT/CY/LV/LT/LU/HU/MT/NL/AT/PL/PT/RO/SI/SK/FI/SE/TR/NO/CH/IS/LI/UK(NI)



Correct Disposal of This Product

This symbol indicates that this electrical or electronic device must not be treated as household waste at the end of its life; instead, it requires separate collection. Free collection points for recycling and reuse are available in your local area. Please contact your municipal authority for these locations. Upon request, authorized retailers may accept up to three old devices free of charge at or near the point of sale. You are required to separate old equipment from general municipal waste. Before returning the device, please remove any batteries, accumulators, or lamps that are not permanently built-in and can be removed without damage. If the device contains personal data, you are responsible for deleting it prior to disposal.

Limited Warranty

This product comes with a 2-year limited warranty that is valid only if purchased from Reolink Official Store or a Reolink authorized reseller. Learn more: https://reolink.com/warranty-and-return/.

NOTE: We hope that you enjoy the new purchase. But if you are not satisfied with the product and plan to return, we strongly suggest that you reset the camera to factory default settings and take out the inserted SD card before returning.

Terms and Privacy

Use of the product is subject to your agreement to the Terms of Service and Privacy Policy at reolink.com

Technical Support

If you need any technical help, please visit our official support site and contact our support team before returning the products, https://support.reolink.com.

Terms of Service

By using the Product Software that is embedded on the Reolink product, you agree to the terms&conditions between you and Reolink. Learn more: https://reolink.com/terms-conditions/

Trademarks Acknowledgement

"Reolink" and other Reolink's trademarks and logos are the properties of Reolink. Other trademarks and logos mentioned are the properties of their respective owners.