How to Initially Setup Reolink Home Hub Series via Reolink Software

Discover how to effortlessly set up your Reolink Home Hub Pro or Reolink Home Hub with our step-by-step guide. Whether you've just unboxed your Reolink Home Hub Pro or the standard Reolink Home Hub, this comprehensive guide will walk you through the initial setup process using both the Reolink App and Reolink Client software.

> **Applies to:** Reolink Home Hub Pro, Hub P1, Reolink Home Hub, Hub 1.

Table of Contents

- Reolink Home Hub Setup on Reolink App
- Reolink Home Hub Setup on Reolink Client

Before We Begin

Ensure your Reolink Home Hub is powered on and connected to your router using a network cable before proceeding with the software setup.



Reolink Home Hub Setup via Reolink App

Step 1. Scan & Connect

1. Launch the Reolink App on your smartphone.
2. Tap the ⊕ icon to add a new device.
3. Scan the QR code on your Reolink Home Hub.



You haven't added any devices. Please click the "+" button in the top right corner to add one.

Scan the QR code on the device.

Or add devices in the following ways

Step 2. Initialize

Wait for the device to finish initializing.



Start initialization soon...

Step 3. Set Username & Password

Enter a unique username and a strong password. Tap **Next** to proceed.



The account info is required when you access device(s) on other platforms. Keep it for quicker access.

admin(Default device account)

Enter device password

Confirm password

Password must contain at least two types of characters from the following: numbers, uppercase letters, lowercase letters, and special characters (including space and !"#$ %&'()*+,-./:;<=>?@[\]^_`{|}~).

Illegal Login Lockout ●

After a series of failed attempts within 3 minutes, your account will be temporarily locked for a few minutes.

Step 4. Name Your Hub

Assign a unique name to your Home Hub for easy identification.



Reolink Home Hub

Step 5. Finish Initialization

Upon seeing "**Initialization Finished**," you'll be introduced to **File Encryption** and **Event Log** features. Explore or **skip** to configure later.



For more configurations, please go to the Device settings to proceed.

☑ Save the QR code of the device to album for sharing, adding or maintaining the device later.

Reolink Home Hub Setup on Reolink Client

Step 1. Add Device

1. Open Reolink Client and click **Add Device** in the upper left corner.
2. Choose to add your Home Hub via UID/IP address or through LAN.



Scan Device(s) in LAN

Reolink Home Hub
UID 9527000HW26PIK5I
Port 9000
IP Address 192.168.68.56
MAC Address ec:71:db:72:b7:f8

812A
UID 95270003109I5GYC
Port 9000
IP Address 192.168.68.27
MAC Address ec:71:db:ca:c5:3d

Step 2. Set Password

Set a secure password for your Home Hub. Click **Next** to continue.



Password Type Here

Confirm Password Type Here

Password must contain at least two types of characters from the following: numbers, uppercase letters, lowercase letters, and special characters (including !"#$%&'()*+,-./:;<=>?@[]^_`{|}~ and space).

Illegal Login Lockout ●

After a series of failed attempts within 3 minutes, your account will be temporarily locked for a few minutes.

Step 3. Name Your Hub

Set a name for your Home Hub. Click **Next**.



Name Reolink Home Hub

Step 4. Complete the Setup

Click **Finish** to finalize the setup. Your Home Hub will now appear in your device list, ready for use.



For more configurations, please go to the Device settings to proceed.