Reolink

Reolink Elite SE WiFi


Operational Instructions



@ReolinkTech https://reolink.com


Item No.: W720

01 What's in the Box



1. Camera
2. Mounting Template
3. Metal Plate (Magnet-Ready)
4. Power Adapter
5. Pack of Screws
6. Surveillance Sticker
7. Operational Instructions

02 Device Overview



1. Microphone
2. Lens
3. Indicator Light
4. Spotlight & IR LEDs
5. Reset Button

* Press and hold the Reset Button for 10 seconds to restore factory settings.

6. microSD Card Slot
7. Silicone Plug
8. Speaker
9. Power Port
10. Magnetic Bracket

03 Set Up the Camera

Step 1. Download the Reolink App or Client

• **On Smartphone**


Download on the App Store

GET IT ON Google Play

• **On PC**

Download the Reolink Client: Go to https://reolink.com > Support > Download Center > App & Client.

Step 2. Power on the Camera




NOTE:
When powered on, the status light flashes blue.

Status Light:
- **Solid Blue:** Device is on and connected.
- **Flashing Blue:** Device is starting up or network error detected.
- **Off:** No power.

Step 3. Initialize the Camera


Tap the "+" button in the top corner, scan the camera's QR code, and follow the on-screen instructions to complete the setup.



NOTE:
Make sure your phone's Bluetooth is on (required for setup).
For Reolink Client users: Click "Add Device" and enter the camera's UID (found below the QR code).

Step 4. Insert the microSD Card (Optional)

Open the rubber plug and insert the microSD card (sold separately). Ensure the cover is securely closed.



NOTE:
Supports microSD cards up to 512GB (Class 10 or higher recommended).

04 Maintenance Guidelines

Tip 1. Mounting for Optimal Image Quality

Ensure both the camera location and the monitored area are evenly lit.

• **Avoid pointing at light sources or directly at windows to prevent flare and overexposure.**

• **Avoid installing in deep shade; position the camera to face a well-lit zone.**

Tip 2. Protecting Your Camera


• **Keep the power port dry and free from dirt/debris to maintain its resistance.**

Tip 3. Regular Maintenance


• **Periodically clean the lens gently with a soft cloth.**

05 Installation Tips

1 Recommended Mounting Height



2 Adjustable Angles




ATTENTION:
Avoid facing reflective objects (tables/walls/windows) to prevent glare.
For outdoor use, ensure the microSD card slot faces downward to prevent water ingress.

06 Installation Steps

Option 1. Magnetic Mounting


A Attach directly to a metal surface.



B Use the included Metal Plate:

1 Peel off the backing and press firmly onto a clean, flat surface.


2 Attach the camera.



NOTE:
Adhesive is for one-time use only. Do not reuse to ensure proper adhesion.

Option 2. Wall/Ceiling Mounting


1 **Remove the two small plugs from the bracket.**



2 **Drill holes according to the mounting template.**



3 **Install the mount base with the screws.**




NOTE:
Use drywall anchors if needed.

Option 3. Tabletop Placement

1 **Place on a flat surface.**



2 **Adjust camera angle.**



NOTE:
For extra stability, secure with the magnetic base or screws.

07 Specifications

Operating Temperature: -10°C ~+55°C (14°F~131°F)
Operating Humidity: 10%~90%
Weight: 268g
Weatherproof: IP67
For additional specifications, please visit https://reolink.com/.

08 Important Safety Instructions

Please read the instructions carefully before using the device.

1. Replace only with the same or equivalent type of accessories recommended by Reolink.
2. Do not use the device in an environment that exceeds the recommended temperature range.
3. Do not use the device in an environment that exceeds the recommended humidity range.
4. Do not attempt to disassemble, repair, or alter the device by yourself.
5. Always follow the local safety laws and regulations when using the device.
6. The device contains (or comes with) small components, small plastic elements, and other small parts that may cause choking hazards. Keep the device and its accessories out of reach of children. Consult a physician immediately if small parts are swallowed.
7. The device contains (or comes with) cables or cords that may cause strangulation hazards. Keep the device and its accessories out of reach of children.

09 Troubleshooting

Camera Is Not Powering On

If your camera is not powering on, please try the following solutions:

- Plug the camera into another outlet.
- Use another 5V/1.6A power adapter to power up the camera.

If these won't work, contact Reolink Support https://support.reolink.com/

Wi-Fi Connection Failed During initial setup

If the camera failed to connect to Wi-Fi during setup, please try:

- Please ensure you have entered the correct Wi-Fi password.
- Put your camera close to your router to ensure a strong Wi-Fi signal.
- Change the encryption method of the WiFi network to WPA2-PSK/WPA-PSK (safer encryption) on your router interface.
- Change your Wi-Fi SSID or password and make sure that SSID is within 31 characters and password is within 64 characters.
- Set your password using only the characters on the keyboard.

If these won't work, contact Reolink Support https://support.reolink.com/

Camera Doesn't Work Properly When Added to the Reolink NVR or Home Hub

If your Reolink camera isn't working properly after being added to an NVR or Home Hub, please make sure the firmware on your camera, NVR, and Hub is updated to the latest version. If the issue continues after updating, contact Reolink Support at https://support.reolink.com/.

10 Legal Disclaimer

To the maximum extent permitted by applicable law, this document and the product described, with its hardware, software, firmware, and services, are delivered on an "as-is" and "as-available" basis, with all faults and without warranty of any kind. Reolink disclaims all warranties, express or implied,

including but not limited to, warranties of merchantability, satisfactory quality, fitness for a particular purpose, accuracy, and non-infringement of third-party rights. In no event will Reolink, its directors, officers, employees, or agents be liable to you for any special, consequential, incidental or indirect damages, including but not limited to damages for loss of business profits, business interruption, or loss of data or documentation, in connection with the use of this product, even if Reolink has been advised of the possibility of such damages.

To the extent permitted by applicable law, your use of the Reolink products and services is at your sole risk and you assume all risks associated with internet access. Reolink does not take any responsibilities for abnormal operation, privacy leakage or other damages resulting from cyber attacks, hacker attacks, virus inspections, or other internet security risks. However, Reolink will provide timely technical support if required.

The laws and regulations related to this product vary by jurisdiction. Please check all relevant laws and regulations in your jurisdiction before using this product to ensure that your use conforms to the applicable law and regulation. During the use of the product, you must comply with relevant local laws and regulations. Reolink is not responsible for any illegal or improper use and its consequences. Reolink is not liable in the event that this product is used with illegitimate purposes, such as third-party rights infringement, medical treatment, safety equipment, or other situations where the product failure could lead to death or personal injury, or for weapons of mass destruction, chemical and biological weapons, nuclear explosion, and any unsafe nuclear energy uses or anti-humanity purposes. In the event of any conflicts between this manual and the applicable law, the latter prevails.

11 Notification of Compliance

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

ISED Statement

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:
(1) this device may not cause interference, and
(2) this device must accept any interference, including interference that may cause undesired operation of the device.
This equipment should be installed and operated with a minumum distance of 20 cm between the radiator and your body.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :
(1) l'appareil ne doit pas produire de brouillage, et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre la source de rayonnement et votre corps.

MODIFICATION: Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the device.

MODIFICATION : les changements ou modifications non expressément approuvés par le fournisseur de licence de l'appareil sont susceptibles d'annuler l'autorisation accordée à l'utilisateur de se servir de l'équipement.

This Class B digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Operation of 5150-5350 MHz is restricted to indoor use only.
Le fonctionnement de 5150-5350 MHz est limité à une utilisation en intérieur uniquement.

Limited Warranty

This product comes with a 2-year limited warranty that is valid only if purchased from Reolink Official Store or a Reolink authorized reseller. Learn more: https://reolink.com/warranty-and-return/.

NOTE: We hope that you enjoy the new purchase. But if you are not satisfied with the product and plan to return, we strongly suggest that you reset the camera to factory default settings and take out the inserted SD card before returning.

Terms and Privacy

Use of the product is subject to your agreement to the Terms of Service and Privacy Policy at reolink.com

Terms of Service

By using the Product Software that is embedded on the Reolink product, you agree to the terms&conditions between you and Reolink. Learn more: https://reolink.com/terms-conditions/

Technical Support

If you need any technical help, please visit our official support site and contact our support team before returning the products, https://support.reolink.com.

Trademarks Acknowledgement

"Reolink" and other Reolink's trademarks and logos are the properties of Reolink. Other trademarks and logos mentioned are the properties of their respective owners.

EZTECH DIGITAL INC.
251 Little Falls Drive, Wilmington, New Castle Country, Delaware 19808

58.03.010.0246