


Flashing the BLDC Shield with custom software



Toolchain

- › To install the necessary Toolchain for developing software for the BLDC Shield, follow the instructions in the TLE987x getting started guide:
[TLE987x_EvalKit_Getting_Started_Document](#)

Keil uVision and writing software for the TLE987x



Use existing software



- › Go to /03_shield_software/uVision_project_files and choose one of the four projects and open its folder (Bootloader, HALL, FOC, BEMF)
- › Open the *.uvprojx project file in Keil uVision
- › Here the Hall project is shown



Name	Date modified	Type	Size
app	07.03.2019 16:19	File folder	
emo	07.03.2019 16:19	File folder	
Listings	07.03.2019 16:19	File folder	
Objects	14.03.2019 13:03	File folder	
RTE	07.03.2019 16:19	File folder	
BldcBcHall.uvoptx	11.09.2018 09:52	UVOPTX File	14 KB
 BldcBcHall.uvprojx	19.09.2018 14:46	µVision5 Project	45 KB
EventRecorderStub.scvd	11.09.2018 09:49	SCVD File	1 KB
JLinkSettings.ini	08.06.2015 18:26	Configuration setti...	1 KB




Write custom software



- › Follow instructions on how to develop software for the TLE987x EvalKit
- › [TLE987x EvalKit Getting Started Document](#)

Connect Hardware


- › Connect a Segger J-Link device with the Shield (here a J-Link lite Cortex-M was used)
- › Connect the J-Link to your PC via USB
- › Connect the Shield to a 12V power supply
- › The Shield should not be connected to the Arduino when flashing




Build and flash software

- › Build the project and flash it to the BLDC Shield


Build project
Flash project



Build



Flash



Using the batch flasher

- › The file TLE9879_Shield_Flash.bat in /03_shield_software/batch_flashing_shield_software/ flashes the four *.hex files to the Shield
- › The *.hex files are from the projects in the /03_shield/uVision_project_files/ folder
- › Use the batch flasher in case you want to factory reset the Shield software

Name	Date modified	Type	Size
 all_applications.jlinkscript	11.01.2019 10:50	JLINKSCRIPT File	1 KB
 bemf.hex	25.09.2018 10:09	HEX File	59 KB
 bootloader.hex	19.09.2018 10:22	HEX File	15 KB
 foc.hex	23.01.2019 18:21	HEX File	90 KB
 hall.hex	19.10.2018 09:35	HEX File	48 KB
 JLink.exe	29.09.2017 16:50	Application	225 KB
 JLinkARM.dll	29.09.2017 16:50	Application extens...	14,501 KB
 TLE9879_Shield_Flash.bat	11.01.2019 10:48	Windows Batch File	1 KB





Part of your life. Part of tomorrow.