
WEMOS S2 mini - footprint at 1:1 (print at 100 percent, NOT "fit to page")

Check first: the bar below must measure exactly 50 mm with a ruler. If not, the printer is scaling.

50 mm

Hold your real board on top of the print and look through the paper. Which end the USB connector is at is NOT verified here: turn the board until the pin holes line up, then tell me which end the USB is at. Each round pad must sit over a pin hole of the board. Pad rows: A and B are the left two columns, C and D the right two columns; pad 1 of each column is at the top.

Pad centres (mm): column A x=0, B x=2.54, C x=20.32, D x=22.86. Row pitch 2.54, 8 rows (y=0 to 17.78). Pad 1 of column A is square.



Outline = board edge from the KiCad C3 mini footprint (about 25.7 x 34.6 mm). This is NOT yet confirmed against your board: that is what this sheet is for. Source: kicad/HDLC-ESP32-S2/HDLC-ESP32-S2.pretty/WEMOS_S2_mini.kicad_mod