Command Log Sheet

AT Command	Expected Response	Actual	Notes
		Response	(Success/Failure)
AT	ОК	OK	Success - Modem responded
AT+CSQ	+CSQ: <rssi>,<ber> OK</ber></rssi>	+CSQ: 21,0 OK	Success - Signal strength was returned
AT+CMGF=1	ОК	OK	Success – SMS mode set
AT+CMGS="+919400446670" >HI GUYS ^Z	+CMGS: 1 OK	+CMGS: 1 OK	Success- Message was sent successfully
AT+CMGR=1	+CMGR: "REC READ","+919400446670" OK	ERROR	Failure – Message not read