# Link Budget Calculation

Training materials for wireless trainers





#### Goals

- To be able to calculate how far we can go with the equipment we have
- To understand why we need high masts for long links
- To learn about software that helps to automate the process of planning radio links




# Free space loss

 Signal power is diminished by geometric spreading of the wavefront, commonly known as *Free Space Loss*.

The power of the signal is spread over a wave front, the area of which increases as the distance from the transmitter increases. Therefore, the power density

diminishes.



# Free Space Loss (@2.45 GHz)

Using decibels to express the loss and using 2.4 GHz as the signal frequency, the equation for the Free Space Loss is:

$$L_{fs} = 100 + 20*log(D)$$


 ...where L<sub>fs</sub> is expressed in dB and D is in kilometers.

# Free Space Loss (any frequency)


 Using decibels to express the loss and using a generic frequency f, the equation for the Free Space Loss is:

$$L_{fs} = 32,45 + 20*log(D) + 20*log(f)$$

...where L<sub>fs</sub> is expressed in dB, D is in kilometers and f is in MHz.



# Power in a wireless system



# Link budget

- The performance of any communication link depends on the quality of the equipment being used.
- Link budget is a way of quantifying the link performance.
- The received power in an 802.11 link is determined by three factors: transmit power, transmitting antenna gain, and receiving antenna gain.
- If that power, minus the *free space loss* of the link path, is greater than the *minimum received signal level* of the receiving radio, then a link is possible.
- The difference between the minimum received signal level and the actual received power is called the *link margin*.
- The link margin must be positive, and should be maximized (should be at least 10dB or more for reliable links).



54Mbps

15 dBm

+/-1dB



#### Zero Variable Outdoor Wireless Deployment



				PS 4KC, 180MF		
			1CMD CDI			
	100 Process (200 Process 200 P	16MB SDRAM, 4MB Flas				
	1 X 10/100 BASE-TX (Cat. 5, RJ-45) Ethernet Interfa			hernet Interfac		
DECLILATORY / COM	DI TANCE TNEODMA	TTON				
REGULATORY / COM	PLIANCE INFORMA		FCC Part 15.24	7. IC RS210. (		
				YE		
est i						
DIO OPERATING FR	EQUENCY 2412-24	62 MHz				
		RX SPECIFICATIONS				
Tolerance		DataRate	Sensitivity	Tolerance		
+/-1dB	9	1Mbps	-95 dBm	+/-1dB		
+/-1dB	7	2Mbps	-94 dBm	+/-1dB		
+/-1dB	2	5.5Mbps	-93 dBm	+/-1dB		
+/-1dB	8	11Mbps	-90 dBm	+/-1dB		
L / 1dB		6Mbps	02 dBm	1 / 1 dD		
	Ι Σ			+/-1dB		
	ي ا			+/-1dB		
	5	THE REAL PROPERTY AND ADDRESS OF THE PERSON NAMED IN		+/-1dB		
	ف ف			+/-1dB		
	7			+/-1dB		
	2	THE SECOND SECOND		+/-1dB		
	8			+/-1dB		
	Tolerance +/-1dB +/-1dB +/-1dB	Tolerance	ADIO OPERATING FREQUENCY 2412-2462 MHz   RX SPEC	ADIO OPERATING FREQUENCY 2412-2462 MHz   RX SPECIFICATIONS		

54Mbps

-72 dBm

+/-1dB

# Example link budget calculation


Let's estimate the feasibility of a **5 km** link, with one access point and one client radio.

The access point is connected to an antenna with 10 dBi gain, with a transmitting power of 20 dBm and a receive sensitivity of -89 dBm.

The client is connected to an antenna with **14 dBi** gain, with a transmitting power of **15 dBm** and a receive sensitivity of **-82 dBm**.

The cables in both systems are short, with a loss of **2dB** at each side at the 2.4 GHz frequency of operation.


#### AP to Client link



# Link budget: AP to Client link

```
20 dBm (TX Power AP)
+ 10 dBi (Antenna Gain AP)
- 2 dB (Cable Losses AP)
+ 14 dBi (Antenna Gain Client)
- 2 dB (Cable Losses Client)
 40 dB Total Gain
-114 dB (free space loss @5 km)
-73 dBm (expected received signal level)
--82 dBm (sensitivity of Client)
 8 dB (link margin)
```

## Opposite direction: Client to AP




# Link budget: Client to AP link

```
15 dBm (TX Power Client)
+ 14 dBi (Antenna Gain Client)
- 2 dB (Cable Losses Client)
+ 10 dBi (Antenna Gain AP)
- 2 dB (Cable Losses AP)
 35 dB Total Gain
-114 dB (free space loss @5 km)
-78 dBm (expected received signal level)
--89 dBm (sensitivity of AP)
 10 dB (link margin)
```

#### Fresnel Zone

- The First Fresnel Zone is an ellipsoid-shaped volume around the Line-of-Sight path between transmitter and receiver.
- The Fresnel Zone is important to the integrity of the RF link because it defines a volume around the LOS that must be clear of any obstacle for the the maximum power to reach the receiving antenna.
- Objects in the Fresnel Zone as trees, hilltops and buildings can considerably attenuate the received signal, even when there is an unobstructed line between the TX and RX.

# Line of Sight and Fresnel Zones



a free line-of-sight IS NOT EQUAL TO a free Fresnel Zone


#### Fresnel Zone

The radius of the first Fresnel Zone at a given point between the transmitter and the receiver can be calculated as:

```
r = 17.31 * sqrt((d1*d2)/(f*d))
```

- ...where **r** is the radius of the zone in meters, **d1** and **d2** are distances from the obstacle to the link end points in meters, **d** is the total link distance in meters, and **f** is the frequency in MHz.
- Note that this gives you the radius of the zone, not the height above ground. To calculate the height above ground, you need to subtract the result from a line drawn directly between the tops of the two towers.

# Line of Sight and Fresnel Zones



$$r = 17.31 * sqrt((d1 * d2) / (f * d))$$

# Clearance of the Fresnel Zone and earth curvature

This table shows the minimum height above flat ground required to clear 70% of the first Fresnel zone for various link distances at 2.4 GHz.

Notice that earth curvature plays a small role at short distances, but becomes more important as the distance increases.

Distance (km)	1st zone (m)	70% (m)	Earth curvature (m)	Required height (m)
1	5.5	3.9	0.0	3.9
5	12.4	8.7	0.4	9.1
10	17.5	12.2	1.5	13.7
15	21.4	15.0	3.3	18.3
20	24.7	17.3	5.9	23.2
25	27.7	19.4	9.2	28.6
30	30.3	21.2 <sup>1</sup>	<sup>9</sup> 13.3	34.5

#### Fresnel Zone

- Considering the importance of the Fresnel Zone, it is important to quantify the degree to which it can be blocked.
- Typically, 20% 40% Fresnel Zone blockage introduces little to no interference into the link.
- It is better to err to the conservative side allowing no more than 20% blockage of the Fresnel Zone.


#### Radio Mobile

- Radio Mobile is a free tool to aid in the design and simulation of wireless systems.
- It can automatically calculate the power budget of a radio link, calculating the Fresnel zone clearance. It can use digital maps, GIS (Geographical Information Systems), or any other digital map, including maps provided by yourself.
- Runs on Windows 95, 98, ME, NT, 2000 and XP.


http://www.cplus.org/rmw/english1.html

#### Radio Mobile

- Uses Digital terrain Elevation Model for the calculation of coverage, indicating received signal strength at various point along the path.
- Radio Mobile automatically builds a profile between two points in the digital map showing the coverage area and 1st Fresnel zone.
- Different antenna heights can be tried to achieve optimum performance.



#### Radio Mobile



#### Win vs Web Radio Mobile

#### Web version

- Pros: runs on any machine (Linux, Mac, Tablet); does not require big downloads; saves sessions; user friendly
- Cons: requires connectivity; only certain frequencies


#### Windows version


- Pros: runs offline; can use the GPS
- Cons: runs on Windows only; requires big downloads; hard to learn


Visit


http://www.cplus.org/rmw/rmonline.html


and create a new account!





























#### Chuuk link

TR's office: 7.452582 151.844061

Udot School: 7.384819 151.718185

#### Chuuk link

#### Questions to answer:

- 1) How high should the masts be?
- 2) How much output power should the radio give?
- 3) What antennas should we use?

Please use the equipment in the lab to answer.

# Thank you for your attention

For more details about the topics presented in this lecture, please see the book *Wireless Networking in the Developing World*, available as free download in many languages at:

http://wndw.net/

