Chair Wiring Diagram +Msensor 5: front-down-left 0000 00 Right motor 000 sensor 4: back-right 000000 **O**+) Contactor sensor 3: back-left 0000 00 010100 Switch 00000 O⊕ 000 Bluetooth sensor 2: front-right 0000 00 900009 O 0=----24VDC sensor 1: front-left 90009 O sensor 10: right 000000 Control PCB Sabertooth 2x60 sensor 9: left 0000 00 000 +M-Relay Module sensor 8: back-down-right 0000 00 Electric motor brakes Left motor 00000 000 sensor 6: front-down-right 0000 00 Sensor Module PCB sensor 7: back-down-left 000000