SONIC CASCADE

RHYTHM RUMBLE

INSTALLATION GUIDE | May, 2023



WARNINGS

ELECTRONIC COMPONENTS

Sonic Cascade Rhythm Rumble is built with a variety of electronic components, most of which require some special handling. Keep the device away from direct heat, sunlight, water, or any other liquid. Do not keep it unattended while plugged in. Keep away from children. Handle with care: hits, strong taps, and other physical contacts can damage the device or its components. Only use it after making sure that there are no signs of damage.

POTENTIALLY HAZARDOUS MATERIALS

Some of the plastic and other materials used might be hazardous when swallowed or used incorrectly. Make sure that children and animals do not have access to the device while unattended.

FLASHING LIGHTS

Flashing visuals and rapidly changing sounds can cause seizures or other unwanted symptoms in people who have certain medical issues. If unsure about the safety of the device to your health, speak with your doctor first.



Figure 1



For the best experience, use headphones.



To learn fast, start slow and gradually increase the speed when needed.

FIRST STEPS

ASSEMBLING

- 1.) Put the bottom piece on a flat surface. 2.) Stand the two legs in the holes. 3.) Put the device on the top, while making sure that the legs are safely supporting the weight of it. 4.) Place the piano in front of the device, making
- sure that the keys align with the led strips on the device. 5.) Plug in the device.

FIRST STEPS

Wait for the screen (2) to display "Enjoy the show!!". With the mood selector (3) and the speed (BPM) selector (4) set the desired attributes of the music. When ready, turn on the music switch (5). The light display (1) will guide you through playing your freshly created song!

PLAYING

Press the corresponding key when a light reaches the bottom of the screen (1). When multiple lights follow each other in one row (yellow, and green on

(1)) hold the key down until the last light of the row disappears.

If wanted, the mood and speed of the music can be changed with the corresponding selector (3), (4) during the song.

Have fun!



TIPS

Don't be afraid to try different settings.

Be considerate to others, not everyone might enjoy your music.

Be patient. Learning takes time.

Select the correct speed and mood that fit your desire.

Use it together with someone. Sharing is caring.

Music can change the world.

-Ludwig van Beethoven

THANK YOU!

Thank you for using our product, we hope you find as much joy in it, as we did creating it.

Inquires:

+358 10 123 4567 help@soniccascade.rr

Created by:

Keijo Kunnari Riccardo Billiato Jari Höllerer Kadosa Varga

Electronics:

Riccardo Billiato

Software:

Jari Höllerer

Documentation, Team Leading, Creative Help:

Kadosa Varga