## **Watch User Manual**

Welcome to Chel	ys Luxury	Timepieces!
-----------------	-----------	-------------

This manual provides instructions on how to set up and maintain your luxury watch.

## 1. Setting the Time:

- Pull the crown out to the first position.
- Turn clockwise to adjust the time.
- Push the crown back to seal.

## 2. Water Resistance:

- Avoid exposing the watch to high-pressure water.
- Ensure the crown is properly sealed before contact with water.

## 3. Warranty Information:

- Your watch comes with a 2-year limited warranty covering mechanical defects.
- Warranty does not cover damage due to misuse or accidents.

For more details, visit our website: www.chelysluxury.com