Print Exit

1GR-FE EMISSION CONTROL PURGE VALVE INSTALLATION

PROCEDURE



■ 1.INSTALL PURGE VSV

17650G

a. Install the purge VSV with the bolt.

Torque:

9.0 N*m (92 kgf*cm, 80 in.*lbf)

- **b.** Connect the 2 No. 1 fuel vapor feed hoses to the purge VSV and slide the clamp to secure the hoses.
- **c.** Connect the purge VSV connector.
- © 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.