Exit Print

1GR-FE ENGINE MECHANICAL DRIVE BELT INSTALLATION

# **PROCEDURE**




## **■** 1.INSTALL FAN AND GENERATOR V BELT

16361A

#### HINT:

When reusing the fan and generator V belt, check the circumference for wear or cracked back and ribs. Replace any belts with wear or cracked ribs that have reached the core (at 1 point or more) and belts with missing rubber ribs (at 1 point or more).





*1	Vane Pump Assembly
*2	Engine Water Pump Assembly
*3	No. 2 Idler Pulley
*4	Generator Assembly
*5	Cooler Compressor Assembly
*6	No. 1 Idler Pulley
*7	Crankshaft Pulley
*8	V-ribbed Belt Tensioner Assembly

Set the fan and generator V belt onto each part.

While turning the belt tensioner counterclockwise, remove the bar.

### **NOTICE:**

Make sure that the fan and generator V belt is properly installed to each pulley.

Check that the belt fits properly in the ribbed grooves.

Make sure to check by hand that the belt has not slipped out of the grooves on the bottom of the pulley.

© 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.