
CLUTCH CLUTCH RELEASE CYLINDER(for 1GR-FE) COMPONENTS

## **ILLUSTRATION**



*1	CLUTCH RELEASE CYLINDER TO FLEXIBLE HOSE TUBE	*2	NO. 1 CLUTCH HOUSING COVER
*3	RELEASE CYLINDER BLEEDER PLUG	*4	ВООТ
*5	PUSH ROD	*6	PISTON
*7	CYLINDER CUP	*8	SPRING
*9	CLUTCH RELEASE CYLINDER BODY	*10	BLEEDER PLUG CAP
	N*m (kgf*cm, ft.*lbf): Specified torque	*	For use with union nut wrench

•	Non-reusable part	<b>→</b>	Lithium soap base glycol grease

© 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.