Print Exit

PREPARATION H150F MANUAL TRANSMISSION / TRANSAXLE EQUIPMENT

Torque wrench	-
Caliper gauge	-
Cylinder gauge	-
Micrometer	-
Dial indicator with magnetic base	-
Protective tape	-
Press	-
Cloth	-

^{© 2012} TOYOTA MOTOR CORPORATION. All Rights Reserved.