

EXTERIOR PANELS / TRIM QUARTER PANEL WHEEL OPENING MOULDING(for Model Code #J76 Series) COMPONENTS

ILLUSTRATION



*1	REAR NO. 1 WHEEL OPENING BRACKET REAR LH	*2	REAR NO. 2 WHEEL OPENING EXTENSION PAD
*3	REAR NO. 2 WHEEL OPENING EXTENSION SUB-ASSEMBLY LH	T 4	REAR NO. 3 WHEEL OPENING BRACKET REAR LH
*5	REAR NO. 3 WHEEL OPENING EXTENSION PAD	l ^h	REAR NO. 8 WHEEL OPENING BRACKET REAR LH
*7	REAR QUARTER PANEL MUDGUARD SUB- ASSEMBLY LH	*8	RIVET
•	Non-reusable part	-	-

ILLUSTRATION



*1	REAR NO. 1 WHEEL OPENING EXTENSION PAD	1 1	REAR NO. 1 WHEEL OPENING EXTENSION SUB-ASSEMBLY LH
*3	REAR NO. 2 WHEEL OPENING BRACKET FRONT LH	- ΛΔ	REAR NO. 3 WHEEL OPENING BRACKET FRONT LH
*5	REAR NO. 4 WHEEL OPENING BRACKET FRONT LH	*6	RIVET
•	Non-reusable part	-	-