

1GR-FE ENGINE CONTROL IGNITION SYSTEM PARTS LOCATION

ILLUSTRATION




*1	ECM (for LHD)	*2	ECM (for RHD)
*3	FUSE BLOCK ASSEMBLY - AM2 FUSE	-	-

ILLUSTRATION



ILLUSTRATION



*1	CRANKSHAFT POSITION SENSOR	*2	VVT SENSOR (for Bank 1)
*3	VVT SENSOR (for Bank 2)	*4	NOISE FILTER
*5	IGNITION COIL ASSEMBLY	-	-

© 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.