



*A	for 1VD-FTV 76, 78 Series	*B	w/ Dynamic Damper
*C	w/ Distance Plate	-	-
*1	LEAF SPRING DYNAMIC DAMPER	*2	REAR DISTANCE PLATE
*3	REAR SHOCK ABSORBER ASSEMBLY LH	*4	REAR SPRING ASSEMBLY LH
*5	REAR SPRING BUMPER SUB-ASSEMBLY	*6	REAR SPRING PIN BUSH
*7	REAR SPRING SHACKLE BUSH	*8	REAR SPRING U BOLT
*9	REAR U BOLT SEAT SUB-ASSEMBLY	*10	REAR SHOCK ABSORBER BUSH
*11	REAR NO. 1 SHOCK ABSORBER CUSHION WASHER	*12	SHACKLE PLATE
*13	SHACKLE PIN	*14	HANGER PIN

	N*m (kgf*cm, ft.*lbf): Specified torque	•	Non-reusable part	
*a	Semi Long Body Type	*b	Long Body Type	




	*11	SHACKLE PLATE	*12	SHACKLE PIN
ſ	*13	HANGER PIN	-	-
		N*m (kgf*cm, ft.*lbf): Specified torque	•	Non-reusable part
	*a	Short, Semi Long Body Type	*b	Long, Super Long Body Type




*A	GRJ71, HZJ71 Series (5-LEAF)	-	-
*1	REAR SPRING CENTER BOLT	*2	REAR SPRING CENTER BOLT NUT
*3	REAR SPRING SHACKLE BUSHING	*4	REAR NO. 1 LEAF SPRING
*5	REAR NO. 2 LEAF SPRING	*6	REAR NO. 3 LEAF SPRING
*7	REAR NO. 4 LEAF SPRING	*8	REAR NO. 5 LEAF SPRING
		1	

*9	REAR NO. 2 SPRING SILENCER	*10	REAR SPRING CLIP SET HEXAGON BOLT
*11	REAR SPRING CLIP BOLT WASHER	*12	REAR SPRING CLIP BOLT CASE
	N*m (kgf*cm, ft.*lbf): Specified torque	-	-




*A	GRJ76, HZJ76 Series (6-LEAF)	-	-
*1	REAR SPRING CENTER BOLT	*2	REAR SPRING CENTER BOLT NUT
*3	REAR SPRING SHACKLE BUSHING	*4	REAR NO. 1 LEAF SPRING
*5	REAR NO. 2 LEAF SPRING	*6	REAR NO. 3 LEAF SPRING
*7	REAR NO. 4 LEAF SPRING	*8	REAR NO. 1 LEAF HELPER SPRING
*9	REAR NO. 2 LEAF HELPER SPRING	*10	REAR NO. 2 SPRING SILENCER

*11	REAR SPRING CLIP SET HEXAGON BOLT	*12	REAR SPRING CLIP BOLT WASHER
*13	REAR SPRING CLIP BOLT CASE	-	-
	N*m (kgf*cm, ft.*lbf): Specified torque	-	-




*A	VDJ76 Series (6-LEAF)	-	-
*1	REAR SPRING CENTER BOLT	*2	REAR SPRING CENTER BOLT NUT
*3	REAR SPRING SHACKLE BUSHING	*4	REAR SPRING PIN BUSHING
*5	LEAF SPRING DYNAMIC DAMPER	*6	REAR NO. 1 LEAF SPRING
*7	REAR NO. 2 LEAF SPRING	*8	REAR NO. 3 LEAF SPRING
*9	REAR NO. 4 LEAF SPRING	*10	REAR NO. 1 LEAF HELPER SPRING

	N*m (kgf*cm, ft.*lbf): Specified torque	•	Non-reusable part
*15	REAR SPRING CLIP BOLT WASHER	*16	REAR SPRING CLIP BOLT CASE
*13	REAR NO. 3 SPRING SILENCER	*14	REAR SPRING CLIP SET HEXAGON BOLT
*11	REAR NO. 2 LEAF HELPER SPRING	*12	REAR NO. 2 SPRING SILENCER




*A	VDJ78 Series (8-LEAF)	-	-
*1	REAR SPRING CENTER BOLT	*2	REAR SPRING CENTER BOLT NUT
*3	REAR SPRING SHACKLE BUSHING	*4	REAR SPRING PIN BUSHING
*5	LEAF SPRING DYNAMIC DAMPER	*6	REAR NO. 1 LEAF SPRING
*7	REAR NO. 2 LEAF SPRING	*8	REAR NO. 3 LEAF SPRING

*9	REAR NO. 4 LEAF SPRING	*10	REAR NO. 5 LEAF SPRING
*11	REAR NO. 6 LEAF SPRING	*12	REAR NO. 7 LEAF SPRING
*13	REAR NO. 8 LEAF SPRING	*14	REAR SPRING CLIP SET HEXAGON BOLT
*15	REAR SPRING CLIP BOLT CASE	-	-
	N*m (kgf*cm, ft.*lbf): Specified torque	•	Non-reusable part




*A	GRJ78, HZJ78 Series (8-LEAF)	-	-
*1	REAR SPRING CENTER BOLT	*2	REAR SPRING CENTER BOLT NUT
*3	REAR SPRING SHACKLE BUSHING	*4	REAR NO. 1 LEAF SPRING
*5	REAR NO. 2 LEAF SPRING	*6	REAR NO. 3 LEAF SPRING

*7	REAR NO. 4 LEAF SPRING	*8	REAR NO. 5 LEAF SPRING
*9	REAR NO. 6 LEAF SPRING	*10	REAR NO. 7 LEAF SPRING
*11	REAR NO. 8 LEAF SPRING	*12	REAR SPRING CLIP SET HEXAGON BOLT
*13	REAR SPRING CLIP BOLT CASE	-	-
	N*m (kgf*cm, ft.*lbf): Specified torque	-	-



*A	GRJ79, HZJ79, VDJ79 Series (8-LEAF)	-	-
*1	REAR SPRING CENTER BOLT	*2	REAR SPRING CENTER BOLT NUT
*3	REAR SPRING SHACKLE BUSHING	*4	REAR NO. 1 LEAF SPRING
*5	REAR NO. 2 LEAF SPRING	*6	REAR NO. 3 LEAF SPRING

*7	REAR NO. 4 LEAF SPRING	*8	REAR NO. 5 LEAF SPRING
*9	REAR NO. 6 LEAF SPRING	*10	REAR NO. 7 LEAF SPRING
*11	REAR NO. 8 LEAF SPRING	*12	REAR NO. 3 SPRING SILENCER
*13	REAR SPRING CLIP SET HEXAGON BOLT	*14	REAR SPRING CLIP BOLT CASE
	N*m (kgf*cm, ft.*lbf): Specified torque	-	-



*A	GRJ79, HZJ79 Series (11-LEAF)	-	-
*1	REAR SPRING CENTER BOLT	*2	REAR SPRING CENTER BOLT NUT
*3	REAR SPRING SHACKLE BUSHING	*4	REAR NO. 1 LEAF SPRING
*5	REAR NO. 2 LEAF SPRING	*6	REAR NO. 3 LEAF SPRING

*7	REAR NO. 4 LEAF SPRING	*8	REAR NO. 5 LEAF SPRING
*9	REAR NO. 6 LEAF SPRING	*10	REAR NO. 7 LEAF SPRING
*11	REAR NO. 8 LEAF SPRING	*12	REAR NO. 9 LEAF SPRING
*13	REAR NO. 10 LEAF SPRING	*14	REAR NO. 11 LEAF SPRING
*15	REAR SPRING CLIP SET HEXAGON BOLT	*16	REAR SPRING CLIP BOLT WASHER
*17	REAR SPRING CLIP BOLT CASE	-	-
	N*m (kgf*cm, ft.*lbf): Specified torque	-	-

^{© 2012} TOYOTA MOTOR CORPORATION. All Rights Reserved.