Print

FRONT SUSPENSION FRONT SHOCK ABSORBER INSTALLATION

CAUTION / NOTICE / HINT

HINT:

- · Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.


PROCEDURE

_


1.INSTALL FRONT SHOCK ABSORBER ASSEMBLY LH

48520

Exit




Install the 2 front No. 2 shock absorber cushion retainers and front No. 1 shock absorber cushion retainer to the front shock absorber assembly LH.



Install the front No. 2 shock absorber cushion retainer and front shock absorber assembly LH with a new nut. **HTNT**.

Install the front No. 2 shock absorber cushion retainer in the direction shown in the illustration.



| Ρ. | |
|----|------------------------------|
| *a | Torque Wrench Fulcrum Length |
| *b | Long Offset Wrench |
| *c | Hexagon Wrench |


Secure the width across flats of the front shock absorber assembly LH and using a 14 mm hexagon wrench and 14 mm x 17 mm long offset wrench, install the front shock absorber assembly LH with a new nut.

Specified tightening torque: 68.6 N*m (700 kgf*cm, 51 ft.*lbf)

HINT:

- Calculate the torque wrench reading when changing the fulcrum length of the torque wrench. Click hereGeneral>INTRODUCTION>REPAIR INSTRUCTION>PRECAUTION
- When using long offset wrench (fulcrum length of 229.75 mm (9.0453 in.)) + torque wrench (fulcrum length of 255 mm (10.0394 in.)): 36.1 N*m (368 kgf*cm, 27 ft.*lbf)






Install the front No. 2 shock absorber cushion retainer, front No. 1 shock absorber cushion retainer and front shock absorber assembly with a new nut.

HINT:

Install the front No. 1 shock absorber cushion retainer and front No. 2 shock absorber cushion retainer in the direction shown in the illustration.



| *a | Torque Wrench Fulcrum Length |
|----|------------------------------|
| *b | Long Offset Wrench |
| *c | Hexagon Wrench |

Secure the width across flats of the front shock absorber assembly LH and using a 14 mm hexagon wrench and 14 mm x 17 mm long offset wrench, install the front shock absorber assembly LH with a new nut.

Specified tightening torque: 68.6 N*m (700 kgf*cm, 51 ft.*lbf)

HINT:

- Calculate the torque wrench reading when changing the fulcrum length of the torque wrench. Click hereGeneral>INTRODUCTION>REPAIR INSTRUCTION>PRECAUTION
- When using long offset wrench (fulcrum length of 229.75 mm (9.0453 in.)) + torque wrench (fulcrum length of 255 mm (10.0394 in.)): 36.1 N*m (368 kgf*cm, 27 ft.*lbf)

_ 2.INSTALL FRONT WHEEL

Click hereSuspension>TIRE / WHEEL>TIRE AND WHEEL>INSTALLATION

© 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.