
Print Exit

1GR-FE ENGINE MECHANICAL DRIVE BELT PRECAUTION

NOTICE:

• Do not apply or add any oil or grease to the belt tensioner to prevent abnormal noises from the belt tensioner pulley, belt squealing, etc.



Do not allow oil or grease to adhere to the moving parts of the belt tensioner, as this may cause malfuntions. if oil or grease is on the location indicated by the arrow, replace the belt tensioner.

© 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.