
WINCH WINCH SYSTEM PARTS LOCATION

## **ILLUSTRATION**



*1	WINCH MAIN RELAY (for 1GR-FE LHD)	*2	WINCH MAIN RELAY (for 1GR-FE RHD, 1HZ)
*3	WINCH UNIT (WINCH ASSEMBLY) - WINCH MOTOR	-	-