AXLE AND DIFFERENTIAL REAR DIFFERENTIAL CARRIER ASSEMBLY(for LSD) INSTALLATION

### **PROCEDURE**


## 1.INSTALL REAR DIFFERENTIAL CARRIER SUB-ASSEMBLY

41101

a. Clean the contact surfaces of the rear differential carrier sub-assembly and axle housing.

Be careful not to damage the installation surface.

b.



Install the rear differential carrier sub-assembly, and a new gasket and the washers with the 10 nuts.

#### **Torque:**


72 N\*m (734 kgf\*cm, 53 ft.\*lbf)

#### **NOTICE:**

Be careful to install the gasket without tearing it.

### 2.INSTALL WIRE HARNESS CLAMP BRACKET (w/ ABS)

a.



Install the wire harness clamp bracket with the nut.

### Torque:

36 N\*m (367 kgf\*cm, 27 ft.\*lbf)

**b.** Connect the clamp.

### **3.INSTALL REAR AXLE SHAFT ASSEMBLY**

Click hereDrivetrain>AXLE AND DIFFERENTIAL>REAR AXLE SHAFT>INSTALLATION



37110

# Click hereDrivetrain>DRIVE SHAFT / PROPELLER SHAFT>PROPELLER SHAFT ASSEMBLY>INSTALLATION

© 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.