Print Exit

1GR-FE COOLING THERMOSTAT INSTALLATION

PROCEDURE

■ 1.INSTALL WATER INLET WITH THERMOSTAT

16031

a. Install a new gasket and the water inlet with thermostat with the 3 nuts.

Torque:

9.0 N*m (92 kgf*cm, 80 in.*lbf)

2.INSTALL NO. 2 RADIATOR HOSE

16572D

Click hereEngine / Hybrid System>1GR-FE COOLING>RADIATOR>INSTALLATION

3.ADD ENGINE COOLANT

Click hereEngine / Hybrid System>1GR-FE COOLING>COOLANT>REPLACEMENT

4.INSPECT FOR COOLANT LEAK

Click hereEngine / Hybrid System>1GR-FE COOLING>COOLING SYSTEM>ON-VEHICLE INSPECTION

5.INSTALL NO. 2 ENGINE UNDER COVER

51442

Click hereEngine / Hybrid System>1GR-FE COOLING>RADIATOR>INSTALLATION

© 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.