PREPARATION 1VD-FTV ENGINE MECHANICAL SST

	09201-10000	Valve Guide Bushing Remover & Replacer Set	-
	(09201-01060)	Valve Guide Bushing	_
	(03201 01000)	Remover & Replacer 6	
	09201-41020	Valve Stem Oil Seal Replacer	-
	09202-70020	Valve Spring Compressor	_
	(09202-00010)	Attachment	-
	09223-56010	Crankshaft Rear Oil Seal Replacer	-
-5			
	09276-75010	Valve Lifter Tool	-
	09316-12010	Transfer Bearing Replacer	-
	09843-18040	Diagnosis Check Wire No. 2	-

1	I	I	1
O. C.			
0			
	09950-00020	Boaring Domovor	
	09930-00020	Bearing Remover	-
ì			
Sales S			
 •			
-11			
	09950-00030	Bearing Remover Attachment	-
		recomment	
200			
	09950-40011	Puller B Set	
	09930-40011	ruller b Set	-
@			
N. Spirite			
	(09957-04010)	Attachment	-
100 miles - 100 miles			
9 2			
CIR 40 G OSS			
The same of the			
	09950-50013	Puller C Set	-
	(09951-05010)	Hanger 150	-
الحدا الحدا			
	(09952-05010)	Slide Arm	-
0.28			
Edition			
53311111111111111111111111111111111111			
2) Thirming			
	(09953-05020)	Center Bolt 150	_
	(00000 00000)		
CITI			
OF			
	(000E4 0E031)	Claw No. 3	
	(09954-05031)	Claw No.3	-
The se committees	09950-60010	Replacer Set	-
CONTINUED IN	I	I	1

CENTREPOSO			
Se occasio o			
	(09951-00180)	Replacer 18	_
(A)			
A STATE OF THE STA	(00054 00250)	Dealers 25	
	(09951-00250)	Replacer 25	-
	(09951-00350)	Replacer 35	-
(0)			
	(09951-00580)	Replacer 58	-
C OO-			
18 19 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9 9			
000000			
	09950-60020	Replacer Set No. 2	_
		Nopiacon Continue	
(8)			
	(09951-00890)	Replacer 89	-
1000			
4//2///			
9000			
	09950-70010	Handle Set	-
Cal			
	(09951-07100)	Handle 100	_
ه			
	(09951-07150)	Handle 150	
		Variable Pin Wrench Set	-
	09960-10010	I variable Pili Wrench Set	

(09962-01000)	Variable Pin Wrench Arm Assembly	-
(09963-01000)	Pin 10	-
00002 00026		
09992-00026	Cylinder Compression Check Gauge Set	-
(09992-00211)	Gauge Assembly	_
(09992-00410)	No.8 Attachment	-

^{© 2012} TOYOTA MOTOR CORPORATION. All Rights Reserved.