Print Exit

CLUTCH CLUTCH PEDAL SWITCH(for 1VD-FTV) REMOVAL

## **PROCEDURE**


1.REMOVE LOWER INSTRUMENT PANEL FINISH PANEL ASSEMBLY

55480D

Click hereVehicle Interior>INTERIOR PANELS / TRIM>INSTRUMENT PANEL SAFETY PAD>REMOVAL

**■ 2.REMOVE CLUTCH SWITCH ASSEMBLY** 

88280A



Disconnect the clutch switch connector.

- **b.** Loosen the lock nut.
- **c.** Remove the clutch switch assembly.

© 2012 TOYOTA MOTOR CORPORATION. All Rights Reserved.