

To create overlays for your Xtouch-Mini, print the **STRIP**, **MIXER**, and **NAV** .JPG templates on cardstock (250g/m², for example, if your printer supports it). Print the templates as they are, at **100% scale**. Choose a high-quality (HD) print setting.

Use a thermal laminator to protect and stiffen the panels. Make sure to let the laminator heat up thoroughly. Next, cut out the holes for the VPOTs and buttons. Personally, I make a single long cutout for the row of VPOTs, another for the upper buttons, and a third for the lower buttons. I use a craft scalpel for the cutting, using a ruler as a guide.

You can choose whether or not to cut the right-hand section separately and tape it to the left-hand section later. The included **.PSD file** allows you to fully customize all the print templates.