9550 300T Tele Tamp Parts

Air Assist Tube Kit:

406689 Spare 300T Right Hand Air Assist Tube Kit

406698 Spare 300T Left Hand Air Assist Tube Kit

Including the air assist tube and set screw that plugs the end of the tube.



Air Assist Pivot Kit (RH and LH):

406683 Spare 300T Right Hand Air Assist Pivot Assembly

406687 Spare 300T Left Hand Air Assist Pivot Assembly

Including all components minus the air assist tube (tube mount, pivot, pipe, air fitting, hardware and air tubing cut to length)




116mm x 110mm and 116mm x 110mm Tamp Pad Kits:

406676 Spare 300T Tamp Pad 116mm x 110mm

406677 Spare 300TT Tamp Pad 110mm x 150mm

Including the tamp pad, mounting screws, and set screws to block unused vacuum holes.



Air Manifold and Gimbal Mount:

406678 Spare 300T Right Hand Air Manifold and Gimbal Mount Assy.

406699 Spare 300T Left Hand Air Manifold and Gimbal Mount Assy.

Including air manifold, gimbal mount, vacuum tubing, sensor magnet, plastic venturi cover and hardware.





Vacuum Venturi Kit:

406679 Spare 300T Vacuum Venturi Kit


Includes vacuum venturi, air fittings, mounting screws, and air tubing cut to length.



Pneumatics Assembly:

406685 Spare 300T Pneumatics Assembly

Including solenoid valve assembly, all air fittings, valve connector cables, flow control valves, mufflers, and all interconnecting air tubes fully assembled. (Does not include air cylinder)



Solenoid Valve Assembly:

406684 Spare 300T Solenoid Valve Assembly


Including the two stacked Rexroth solenoid valves, two mufflers and air fittings.



300mm Air Cylinder:

406682 Spare 300T Air Cylinder


Includes 300mm (11.81") air cylinder, jam nut, and spacer between guide rod mounting block, and the actuating shaft of the air cylinder. Also the screw that holds the spacer to the guide rod mounting block.



Linear Bearing Refurb Kit:

406690 Spare 300T Linear Bearing Refurb Kit


Includes 4 linear bearings and 2 circlips.




Hinge Lock Plunger Assembly: 406691 Spare 300T Hinge Lock Plunger Assembly Includes knob, pin, spring, and hardware.



Tamp Home Sensor Assembly:
406681 Spare 300T Tamp Home Sensor Assembly
Includes tamp home switch, magnet, and hardware.




Product Present Contact Switch:
406680 Spare 300T Pad Sensor Assembly
Includes switch, magnet, and hardware.



Energy Chain:

406692 Spare 300T Energy Chain


Includes energy chain cut to length, mount, and hardware.



Tamp Cable Kit:

406700 Spare 300T Tamp Cable Kit

Includes d-connector cable, tamp home switch extension cable, product present sensor extension cable, and all solenoid valve cables.



9550 Tamp Cable

406314 Tamp Cable

The cable that runs from the 9550's main pcb X14 to a male 15 pin sub D connector that mounts on the 9550's chassis. (Includes mounting screws and nuts) (Labeled 505483-X14)

9550 Tamp Module Circuit Board:

406686 Spare LPA Applicator PCB

Includes tamp circuit board with switches 1 and 2 set to the on position.



Tamp Enclosure End Cap Kit:

406693 Spare 300T Enclosure End Cap Kit


Includes enclosure end cap and cap lock nut.



Guide Rod Set:

406694 Spare 300T Guide Rod Set

Includes (2) guide rods and mounting hardware for each end.



Air Regulator Kit:

406695 Spare 300T Air Regulator Kit

Includes Regulator, Filter bowl, gauge, mount bracket, air fittings, port plug, and tubing. Also air input elbow fitting:



