## **Altair® HyperWorks®**

2022.2

## Add Representations to the Part Library

After importing a BOM, you can add CAD representations to the Part Library.

- 1. In the Part Browser, right-click on a part/part assembly and select **Representations** > (and then) **Add** > (and then) **to Library** from the context menu.
- 2. In the Add Representation to Library dialog, select representations and click OK.

The **Add Representation to Library** dialog displays information regarding the availability of representations in library, session, and overwrite details.

In Figure 1, CAD representations are being added to the Part Library. The Library column displays 0/8, which indicates there are no CAD representations available in the Part Library. The Session column displays 6/8, which indicate 6 out of 8 representations are currently available in the active HyperMesh session. The Overwrite column displays 0/8, which indicates none of the representations will need to be overwritten.




Figure 1.