



37245 數位系統設計與實習

銘傳大學電子工程學系
黃炳森 教授



Course Information

- **Class times**

- 12:50-15:40 Tuesday S301 電子二乙
- 09:10-12:00 Wednesday S301 電子二甲

- **Instructor office hours**

- Prof. Ping-Sheng Huang(黃炳森),
pshuang@mail.mcu.edu.tw
- Office: S635
- Phone: ext. 3435
- Office Hours: Tuesday & Wednesday, 15:50-16:50,
Thursday, 09:00-12:00



Evaluation and Grading

- **Approximately:**
 - 70% Experiment performance and report
 - 30% Midterm exam
- Participating in these is important to your understanding of the topic and **your grade!**



Course Purposes

- This is an advanced version for the undergraduate course of “數位系統設計與實習”, and the design of digital systems in a **hierarchical, top-down** manner.
- The student is also introduced to the use of **computer-aided design tools** to develop complex digital circuits and to prototyping designs using programmable logic devices and field-programmable gate arrays(FPGA).



What You Should Already Know

- **Principles of basic digital logic design (Digital Logic Design)**
 - Number representations
 - Boolean algebra
 - Gate-level design
 - K-Map minimization
 - Combinational logic
 - Synchronous sequential logic
 - Registers and counters
 - Memory and programmable logic



Course Overview

Textbook:

- 黃英叡, 黃稚存 編譯, Verilog 硬體描述語言(附範例光碟片)(第二版), 2019年8月.(全華圖書)

Referred Books and Websites:

- 林銘波, FPGA系統設計實務入門—使用Verilog HDL:Intel/Altera Quartus, 2018年9月.(全華圖書)
- 並木秀明著, 吳忻廷譯, 正確學會Verilog的16堂課, 旗標圖書, 2012.
- [FPGA4student](#)
- [fpga4fun](#)
- [Youtube: FPGA Projects](#)
- [Verilog HDL 教學講義](#)






Course Overview

- Review of Logic Design Fundamentals
- Introduction to Programmable Logic Devices
- Introduction to DE10-Lite, Quartus II and ModelSim-Altera
- Introduction to Verilog HDL
- Digital Logic Design Examples (Combinational & Sequential Circuits)
- DE10-Lite Design Examples
- Small Project Design

Course Overview

- Simulation hardware
 - terasic(友晶科技) DE10-Lite Board開發平台



Course Overview

- Simulation hardware (Demo)




Figure 1-2 Development Board (top view)

Course Overview

- Simulation hardware




Figure 1-3 Development Board (bottom view)



Course Overview

- Simulation software
 - Intel® Quartus® Prime Lite Edition(includes Nios II EDS),
Questa*-Intel® FPGA Edition (Version 18.1)
 - Plenty of resources available on the Web.
 - Quartus is used for writing Verilog HDL, VHDL, Simulation, and Synthesis.
 - The Altera DE10-Lite board is used for implementation
 - Check MCU Moodle system for more course materials!



What You Should Do?

- **In Class**

- Listen carefully and be concentrated
 - Practice hard during the assigned time slot

- **After Class**

- Study hard for those information from the book and the internet
 - Practice actively by yourself!!
 - Practice, Practice, and Practice!!!



Q & A



硬體平台簡介

- 硬體 (<http://www.terasic.com.tw>)
 - 友晶科技 (Terasic) Altera DE 系列實驗板

Board	Device Name
DE0	Cyclone III EP3C16F484C6
DE0-Nano	Cyclone IVE EP4CE22F17C6
DE1	Cyclone II EP2C20F484C7
DE2	Cyclone II EP2C35F672C6
DE2-70	Cyclone II EP2C70F896C6
DE2-115	Cyclone IVE EP4CE115F29C7


表 1-1 DE 系列實驗板 FPGA 名稱

MAX 10 10M50DAF484C7G

硬體平台簡介

• 硬體

– 友晶科技 DE10-Lite 開發板 Block Diagram





硬體平台簡介

• 硬體

– 友晶科技 DE10-Lite 開發板

- FPGA型號 ”MAX 10 10M50DAF484C7G”
- 具有50K個邏輯單元(LEs)
- 外接記憶體 64MB的SDRAM，x16 bits data bus
- 1,638 Kbit M9K Memory
- 5,888 Kbits user Flash 記憶體
- 144 個 18x18 乘法器
- 4 個鎖相環(PLLs)
- 5V DC input



硬體平台簡介

• 硬體

- 友晶科技 DE10-Lite 開發板

- 內建加速規(accelerometer)感測器
- 2x20 GPIO 連接器
- Arduino Uno R3 連接器，包含 6 個 ADC 通道
- 4 位電阻式 VGAA
- 10 個 LED
- 10 個滑動開關
- 2 個去抖動按鈕
- 6 個七段顯示器


硬體平台簡介

- MTL2(Multi-Touch LCD) 與 DE10-Lite 連接示意圖



硬體平台簡介

- Camera (D8M-GPIO 與 D5M) 與 DE10-Lite 連接



硬體平台簡介

- Arduino Shield 與 DE10-Lite 連接



硬體平台簡介




圖 1-4 DE10-Lite 開發板方塊圖

硬體平台簡介

- 時脈電路(Clock Circuitry)




Table 3-2 Pin Assignment of Clock Inputs

Signal Name	FPGA Pin No.	Description	I/O Standard
ADC_CLK_10	PIN_N5	10 MHz clock input for ADC (Bank 3B)	3.3-V LVTTL
MAX10_CLK1_50	PIN_P11	50 MHz clock input(Bank 3B)	3.3-V LVTTL
MAX10_CLK2_50	PIN_N14	50 MHz clock input(Bank 3B)	3.3-V LVTTL


硬體平台簡介

- LED

- DE10-Lite共有10顆紅色LED，每顆都有單腳連接FPGA

Table 3-5 Pin Assignment of LEDs


Signal Name	FPGA Pin No.	Description	I/O Standard
LEDR0	PIN_A8	LED [0]	3.3-V LVTTL
LEDR1	PIN_A9	LED [1]	3.3-V LVTTL
LEDR2	PIN_A10	LED [2]	3.3-V LVTTL
LEDR3	PIN_B10	LED [3]	3.3-V LVTTL
LEDR4	PIN_D13	LED [4]	3.3-V LVTTL
LEDR5	PIN_C13	LED [5]	3.3-V LVTTL
LEDR6	PIN_E14	LED [6]	3.3-V LVTTL
LEDR7	PIN_D14	LED [7]	3.3-V LVTTL
LEDR8	PIN_A11	LED [8]	3.3-V LVTTL
LEDR9	PIN_B11	LED [9]	3.3-V LVTTL



硬體平台簡介

• 七段顯示器

- DE10-Lite共有6個七段顯示器，每段編號從0到6，還有DP





硬體平台簡介

- 七段顯示器(HEX00-HEX57對應腳)

Table 3-6 Pin Assignment of 7-segment Displays

Signal Name	FPGA Pin No.	Description	I/O Standard
HEX00	PIN_C14	Seven Segment Digit 0[0]	3.3-V LVTTL
HEX01	PIN_E15	Seven Segment Digit 0[1]	3.3-V LVTTL
HEX02	PIN_C15	Seven Segment Digit 0[2]	3.3-V LVTTL
HEX03	PIN_C16	Seven Segment Digit 0[3]	3.3-V LVTTL
HEX04	PIN_E16	Seven Segment Digit 0[4]	3.3-V LVTTL
HEX05	PIN_D17	Seven Segment Digit 0[5]	3.3-V LVTTL
HEX06	PIN_C17	Seven Segment Digit 0[6]	3.3-V LVTTL
HEX07	PIN_D15	Seven Segment Digit 0[7], DP	3.3-V LVTTL
HEX10	PIN_C18	Seven Segment Digit 1[0]	3.3-V LVTTL
HEX11	PIN_D18	Seven Segment Digit 1[1]	3.3-V LVTTL
HEX12	PIN_E18	Seven Segment Digit 1[2]	3.3-V LVTTL
HEX13	PIN_B16	Seven Segment Digit 1[3]	3.3-V LVTTL



硬體平台簡介

• 七段顯示器(HEX00-HEX57對應腳)

HEX14	PIN_A17	Seven Segment Digit 1[4]	3.3-V LVTTL
HEX15	PIN_A18	Seven Segment Digit 1[5]	3.3-V LVTTL
HEX16	PIN_B17	Seven Segment Digit 1[6]	3.3-V LVTTL
HEX17	PIN_A16	Seven Segment Digit 1[7] , DP	3.3-V LVTTL
HEX20	PIN_B20	Seven Segment Digit 2[0]	3.3-V LVTTL
HEX21	PIN_A20	Seven Segment Digit 2[1]	3.3-V LVTTL
HEX22	PIN_B19	Seven Segment Digit 2[2]	3.3-V LVTTL
HEX23	PIN_A21	Seven Segment Digit 2[3]	3.3-V LVTTL
HEX24	PIN_B21	Seven Segment Digit 2[4]	3.3-V LVTTL
HEX25	PIN_C22	Seven Segment Digit 2[5]	3.3-V LVTTL
HEX26	PIN_B22	Seven Segment Digit 2[6]	3.3-V LVTTL
HEX27	PIN_A19	Seven Segment Digit 2[7] , DP	3.3-V LVTTL
HEX30	PIN_F21	Seven Segment Digit 3[0]	3.3-V LVTTL
HEX31	PIN_E22	Seven Segment Digit 3[1]	3.3-V LVTTL
HEX32	PIN_E21	Seven Segment Digit 3[2]	3.3-V LVTTL
HEX33	PIN_C19	Seven Segment Digit 3[3]	3.3-V LVTTL
HEX34	PIN_C20	Seven Segment Digit 3[4]	3.3-V LVTTL
HEX35	PIN_D19	Seven Segment Digit 3[5]	3.3-V LVTTL
HEX36	PIN_E17	Seven Segment Digit 3[6]	3.3-V LVTTL
HEX37	PIN_D22	Seven Segment Digit 3[7] , DP	3.3-V LVTTL




硬體平台簡介

• 七段顯示器(HEX00-HEX57對應腳)

HEX40	PIN_F18	Seven Segment Digit 4[0]	3.3-V LVTTL
HEX41	PIN_E20	Seven Segment Digit 4[1]	3.3-V LVTTL
HEX42	PIN_E19	Seven Segment Digit 4[2]	3.3-V LVTTL
HEX43	PIN_J18	Seven Segment Digit 4[3]	3.3-V LVTTL
HEX44	PIN_H19	Seven Segment Digit 4[4]	3.3-V LVTTL
HEX45	PIN_F19	Seven Segment Digit 4[5]	3.3-V LVTTL
HEX46	PIN_F20	Seven Segment Digit 4[6]	3.3-V LVTTL
HEX47	PIN_F17	Seven Segment Digit 4[7] , DP	3.3-V LVTTL
HEX50	PIN_J20	Seven Segment Digit 5[0]	3.3-V LVTTL
HEX51	PIN_K20	Seven Segment Digit 5[1]	3.3-V LVTTL
HEX52	PIN_L18	Seven Segment Digit 5[2]	3.3-V LVTTL
HEX53	PIN_N18	Seven Segment Digit 5[3]	3.3-V LVTTL
HEX54	PIN_M20	Seven Segment Digit 5[4]	3.3-V LVTTL
HEX55	PIN_N19	Seven Segment Digit 5[5]	3.3-V LVTTL
HEX56	PIN_N20	Seven Segment Digit 5[6]	3.3-V LVTTL
HEX57	PIN_L19	Seven Segment Digit 5[7] , DP	3.3-V LVTTL

硬體平台簡介

- 2x20 GPIO 擴充接腳



GPIO (JP1)			
PIN_V10	GPIO_[0]	1	2 GPIO_[1] PIN_W10
PIN_V9	GPIO_[2]	3	4 GPIO_[3] PIN_W9
PIN_V8	GPIO_[4]	5	6 GPIO_[5] PIN_W8
PIN_V7	GPIO_[6]	7	8 GPIO_[7] PIN_W7
PIN_W6	GPIO_[8]	9	10 GPIO_[9] PIN_V5
	5V	11	12 GND
PIN_W5	GPIO_[10]	13	14 GPIO_[11] PIN_AA15
PIN_AA14	GPIO_[12]	15	16 GPIO_[13] PIN_W13
PIN_W12	GPIO_[14]	17	18 GPIO_[15] PIN_AB13
PIN_AB12	GPIO_[16]	19	20 GPIO_[17] PIN_Y11
PIN_AB11	GPIO_[18]	21	22 GPIO_[19] PIN_W11
PIN_AB10	GPIO_[20]	23	24 GPIO_[21] PIN_AA10
PIN_AA9	GPIO_[22]	25	26 GPIO_[23] PIN_Y8
PIN_AA8	GPIO_[24]	27	28 GPIO_[25] PIN_Y7
	3.3V	29	30 GND
PIN_AA7	GPIO_[26]	31	32 GPIO_[27] PIN_Y6
PIN_AA6	GPIO_[28]	33	34 GPIO_[29] PIN_Y5
PIN_AA5	GPIO_[30]	35	36 GPIO_[31] PIN_Y4
PIN_AB3	GPIO_[32]	37	38 GPIO_[33] PIN_Y3
PIN_AB2	GPIO_[34]	39	40 GPIO_[35] PIN_AA2

圖 3-18 DE10-Lite GPIO接腳圖



硬體平台簡介

- 2x20 GPIO 擴充接腳

Table 3-7 Show all Pin Assignment of Expansion Headers

Signal Name	FPGA Pin No.	Description	I/O Standard
GPIO_0	PIN_V10	GPIO Connection [0]	3.3-V LVTTL
GPIO_1	PIN_W10	GPIO Connection [1]	3.3-V LVTTL
GPIO_2	PIN_V9	GPIO Connection [2]	3.3-V LVTTL
GPIO_3	PIN_W9	GPIO Connection [3]	3.3-V LVTTL
GPIO_4	PIN_V8	GPIO Connection [4]	3.3-V LVTTL
GPIO_5	PIN_W8	GPIO Connection [5]	3.3-V LVTTL
GPIO_6	PIN_V7	GPIO Connection [6]	3.3-V LVTTL
GPIO_7	PIN_W7	GPIO Connection [7]	3.3-V LVTTL
GPIO_8	PIN_W6	GPIO Connection [8]	3.3-V LVTTL
GPIO_9	PIN_V5	GPIO Connection [9]	3.3-V LVTTL
GPIO_10	PIN_W5	GPIO Connection [10]	3.3-V LVTTL
GPIO_11	PIN_AA15	GPIO Connection [11]	3.3-V LVTTL
GPIO_12	PIN_AA14	GPIO Connection [12]	3.3-V LVTTL
GPIO_13	PIN_W13	GPIO Connection [13]	3.3-V LVTTL
GPIO_14	PIN_W12	GPIO Connection [14]	3.3-V LVTTL
GPIO_15	PIN_AB13	GPIO Connection [15]	3.3-V LVTTL
GPIO_16	PIN_AB12	GPIO Connection [16]	3.3-V LVTTL
GPIO_17	PIN_Y11	GPIO Connection [17]	3.3-V LVTTL



硬體平台簡介

- 2x20 GPIO 擴充接腳

GPIO_18	PIN_AB11	GPIO Connection [18]	3.3-V LVTTL
GPIO_19	PIN_W11	GPIO Connection [19]	3.3-V LVTTL
GPIO_20	PIN_AB10	GPIO Connection [20]	3.3-V LVTTL
GPIO_21	PIN_AA10	GPIO Connection [21]	3.3-V LVTTL
GPIO_22	PIN_AA9	GPIO Connection [22]	3.3-V LVTTL
GPIO_23	PIN_Y8	GPIO Connection [23]	3.3-V LVTTL
GPIO_24	PIN_AA8	GPIO Connection [24]	3.3-V LVTTL
GPIO_25	PIN_Y7	GPIO Connection [25]	3.3-V LVTTL
GPIO_26	PIN_AA7	GPIO Connection [26]	3.3-V LVTTL
GPIO_27	PIN_Y6	GPIO Connection [27]	3.3-V LVTTL
GPIO_28	PIN_AA6	GPIO Connection [28]	3.3-V LVTTL
GPIO_29	PIN_Y5	GPIO Connection [29]	3.3-V LVTTL
GPIO_30	PIN_AA5	GPIO Connection [30]	3.3-V LVTTL
GPIO_31	PIN_Y4	GPIO Connection [31]	3.3-V LVTTL
GPIO_32	PIN_AB3	GPIO Connection [32]	3.3-V LVTTL
GPIO_33	PIN_Y3	GPIO Connection [33]	3.3-V LVTTL
GPIO_34	PIN_AB2	GPIO Connection [34]	3.3-V LVTTL
GPIO_35	PIN_AA2	GPIO Connection [35]	3.3-V LVTTL

硬體平台簡介

• 按鈕(Button)

- DE10-Lite共有兩個按鈕，這些按鈕都接上了施密特觸發器(Schmitt trigger)來對按鈕去除彈跳(debounce)。




Table 3-3 Pin Assignment of Push-buttons

Signal Name	FPGA Pin No.	Description	I/O Standard
KEY0	PIN_B8	Push-button[0]	3.3 V SCHMITT TRIGGER"
KEY1	PIN_A7	Push-button[1]	3.3 V SCHMITT TRIGGER"

硬體平台簡介

• 指撥開關(Switch)

– DE10-Lite有10個指撥開關(slide switches)，這些開關並未接上施密特觸發器，也因此不具有防彈跳的功能。

Table 3-4 Pin Assignment of Slide Switches



Signal Name	FPGA Pin No.	Description	I/O Standard
SW0	PIN_C10	Slide Switch[0]	3.3-V LVTTL
SW1	PIN_C11	Slide Switch[1]	3.3-V LVTTL
SW2	PIN_D12	Slide Switch[2]	3.3-V LVTTL
SW3	PIN_C12	Slide Switch[3]	3.3-V LVTTL
SW4	PIN_A12	Slide Switch[4]	3.3-V LVTTL
SW5	PIN_B12	Slide Switch[5]	3.3-V LVTTL
SW6	PIN_A13	Slide Switch[6]	3.3-V LVTTL
SW7	PIN_A14	Slide Switch[7]	3.3-V LVTTL
SW8	PIN_B14	Slide Switch[8]	3.3-V LVTTL
SW9	PIN_F15	Slide Switch[9]	3.3-V LVTTL

硬體平台簡介

- **VGA**

- DE10-Lite 支援標準 VGA 解析度 (640x480 pixels, at 25 MHz)。




圖 3-21 DE10-Lite 與 VGA 連接圖



硬體平台簡介

- VGA

- VGA水平與垂直時序規格

Table 3-9 VGA Horizontal Timing Specification

VGA mode		Horizontal Timing Spec				
Configuration	Resolution(HxV)	a(pixel clock cycle)	b(pixel clock cycle)	c(pixel clock cycle)	d(pixel clock cycle)	Pixel clock(MHz)
VGA(60Hz)	640x480	96	48	640	16	25

Table 3-10 VGA Vertical Timing Specification

VGA mode		Vertical Timing Spec				
Configuration	Resolution(HxV)	a(lines)	b(lines)	c(lines)	d(lines)	Pixel clock(MHz)
VGA(60Hz)	640x480	2	33	480	10	25



硬體平台簡介

- VGA(pin assignment for 4-bit DAC)
 - 要控制 VGA 要知道 FGPA 拉出來的接腳

Table 3-11 Pin Assignment of VGA

Signal Name	FPGA Pin No.	Description	I/O Standard
VGA_R0	PIN_AA1	VGA Red[0]	3.3-V LVTTL
VGA_R1	PIN_V1	VGA Red[1]	3.3-V LVTTL
VGA_R2	PIN_Y2	VGA Red[2]	3.3-V LVTTL
VGA_R3	PIN_Y1	VGA Red[3]	3.3-V LVTTL
VGA_G0	PIN_W1	VGA Green[0]	3.3-V LVTTL
VGA_G1	PIN_T2	VGA Green[1]	3.3-V LVTTL
VGA_G2	PIN_R2	VGA Green[2]	3.3-V LVTTL
VGA_G3	PIN_R1	VGA Green[3]	3.3-V LVTTL
VGA_B0	PIN_P1	VGA Blue[0]	3.3-V LVTTL
VGA_B1	PIN_T1	VGA Blue[1]	3.3-V LVTTL
VGA_B2	PIN_P4	VGA Blue[2]	3.3-V LVTTL
VGA_B3	PIN_N2	VGA Blue[3]	3.3-V LVTTL
VGA_HS	PIN_N3	VGA Horizontal sync	3.3-V LVTTL
VGA_VS	PIN_N1	VGA Vertical sync	3.3-V LVTTL

硬體平台簡介

- 64MB SDRAM (32Mx16)




圖 3-21 DE10-Lite 與 SDRAM 連接圖



硬體平台簡介

- **64MB SDRAM (pin assignment)**

Signal Name	FPGA Pin No.	Description	I/O Standard
DRAM_ADDR0	PIN_U17	SDRAM Address[0]	3.3-V LVTTL
DRAM_ADDR1	PIN_W19	SDRAM Address[1]	3.3-V LVTTL
DRAM_ADDR2	PIN_V18	SDRAM Address[2]	3.3-V LVTTL
DRAM_ADDR3	PIN_U18	SDRAM Address[3]	3.3-V LVTTL
DRAM_ADDR4	PIN_U19	SDRAM Address[4]	3.3-V LVTTL
DRAM_ADDR5	PIN_T18	SDRAM Address[5]	3.3-V LVTTL
DRAM_ADDR6	PIN_T19	SDRAM Address[6]	3.3-V LVTTL
DRAM_ADDR7	PIN_R18	SDRAM Address[7]	3.3-V LVTTL
DRAM_ADDR8	PIN_P18	SDRAM Address[8]	3.3-V LVTTL
DRAM_ADDR9	PIN_P19	SDRAM Address[9]	3.3-V LVTTL
DRAM_ADDR10	PIN_T20	SDRAM Address[10]	3.3-V LVTTL
DRAM_ADDR11	PIN_P20	SDRAM Address[11]	3.3-V LVTTL
DRAM_ADDR12	PIN_R20	SDRAM Address[12]	3.3-V LVTTL
DRAM_DQ0	PIN_Y21	SDRAM Data[0]	3.3-V LVTTL
DRAM_DQ1	PIN_Y20	SDRAM Data[1]	3.3-V LVTTL
DRAM_DQ2	PIN_AA22	SDRAM Data[2]	3.3-V LVTTL
DRAM_DQ3	PIN_AA21	SDRAM Data[3]	3.3-V LVTTL
DRAM_DQ4	PIN_Y22	SDRAM Data[4]	3.3-V LVTTL
DRAM_DQ5	PIN_W22	SDRAM Data[5]	3.3-V LVTTL
DRAM_DQ6	PIN_W20	SDRAM Data[6]	3.3-V LVTTL



硬體平台簡介

- **64MB SDRAM (pin assignment)**

DRAM_DQ7	PIN_V21	SDRAM Data[7]	3.3-V LVTTL
DRAM_DQ8	PIN_P21	SDRAM Data[8]	3.3-V LVTTL
DRAM_DQ9	PIN_J22	SDRAM Data[9]	3.3-V LVTTL
DRAM_DQ10	PIN_H21	SDRAM Data[10]	3.3-V LVTTL
DRAM_DQ11	PIN_H22	SDRAM Data[11]	3.3-V LVTTL
DRAM_DQ12	PIN_G22	SDRAM Data[12]	3.3-V LVTTL
DRAM_DQ13	PIN_G20	SDRAM Data[13]	3.3-V LVTTL
DRAM_DQ14	PIN_G19	SDRAM Data[14]	3.3-V LVTTL
DRAM_DQ15	PIN_F22	SDRAM Data[15]	3.3-V LVTTL
DRAM_BA0	PIN_T21	SDRAM Bank Address[0]	3.3-V LVTTL
DRAM_BA1	PIN_T22	SDRAM Bank Address[1]	3.3-V LVTTL
DRAM_LDQM	PIN_V22	SDRAM byte Data Mask[0]	3.3-V LVTTL
DRAM_UDQM	PIN_J21	SDRAM byte Data Mask[1]	3.3-V LVTTL
DRAM_RAS_N	PIN_U22	SDRAM Row Address Strobe	3.3-V LVTTL
DRAM_CAS_N	PIN_U21	SDRAM Column Address Strobe	3.3-V LVTTL
DRAM_CKE	PIN_N22	SDRAM Clock Enable	3.3-V LVTTL
DRAM_CLK	PIN_L14	SDRAM Clock	3.3-V LVTTL
DRAM_WE_N	PIN_V20	SDRAM Write Enable	3.3-V LVTTL
DRAM_CS_N	PIN_U20	SDRAM Chip Select	3.3-V LVTTL



Software Installation

- 1) Download and install “Intel® Quartus® Prime Lite Edition Version 18.1 for Windows” (Free)

The screenshot shows the Intel FPGA Software Download Center. At the top, there's a navigation bar with links for PRODUCTS, SUPPORT, SOLUTIONS, DEVELOPERS, PARTNERS, and FOUNDRY. On the right, there are user profile and language selection (ENGLISH) options, along with a search bar. Below the navigation bar, a sub-header reads "FPGA Software Download Center". The main content area features a large banner for "Intel® Quartus® Prime Lite Edition Design Software Version 18.1 for Windows". Below the banner is a table with the following columns: ID, Date, Software Type, Software Package, Version, and Operating Systems. The data in the table is as follows:

ID	Date	Software Type	Software Package	Version	Operating Systems
665990	9/23/2018	FPGA Development	Quartus® Prime Lite	18.1	Windows

Below the table, a yellow banner states: "A newer version of this software is available, which includes functional and security updates. Customers should click here to update to the latest version." A "Feedback" button is located on the left side of this banner. At the bottom of the page, there's a note for users about upgrading to the latest version, a statement about the software being subject to removal, and links to critical issues and patches.

Users should upgrade to the latest version of the Intel® Quartus® Prime Design Software. The selected version does not include the latest functional and security updates. If you must use this version of software, follow the [technical recommendations](#) to help improve security. For critical support requests, please contact our [support team](#).

The Intel® Quartus® Prime Edition Design Software, Version 18.1 is subject to removal from the web when support for all devices in this release are available in a newer version, or all devices supported by this version are obsolete. If you would like to receive customer notifications by e-mail, please subscribe to our [customer notification mailing list](#).

[Critical Issues and Patches for the Intel® Quartus® Prime Lite Edition Software, Version 18.1.](#)
[Knowledge Base: Search for Errata.](#) Also see Critical Issues and Patches.
[Problems and Answers on specific IP or Products.](#)



Software Installation

- Download the following, on “Individual Files” tab:
 - ModelSim-Intel® FPGA Edition (includes Starter Edition)
 - Intel® Quartus® Prime (includes Nios® II EDS)
 - Devices - Intel® MAX® 10 Device Support

Downloads

The screenshot shows a software download interface with the following details:


- Downloads** tab selected.
- Individual Files** tab is active.
- Intel® Quartus® Software** section:
 - ModelSim-Intel® FPGA Edition (includes Starter Edition)**
 - Download** button (blue background, white text): ModelSimSetup-18.1.0.625-windows.exe
 - Size: 1.1 GB
 - SHA1: f4b428584c780016d119c0b1fd16c26dee880dcc
 - Intel® Quartus® Prime (includes Nios® II EDS)**
 - Download** button (blue background, white text): QuartusLiteSetup-18.1.0.625-windows.exe
 - Size: 1.7 GB
 - SHA1: 70faf36e2c8d69aa5243de767242a75832fa749e

Software Installation

- Once you downloaded the above three files, install **QuartusLiteSetup-18.1.0.625-windows.exe**, which will select to install the other two as well. In my case, all were installed in: **C:\intelFPGA_lite\18.1**

Minimum Disk

- Intel® Quartus® Prime Lite Edition Design Software (14 GB)




本機 > 本機 > 下載 > Quartus-lite-18.1.0.625-windows				
	名稱	修改日期	類型	大小
本機	cyclone-18.1.0.625.qdz	2018/9/13 下午 07:58	QDZ 檔案	477,849 KB
3D Objects	cyclonev-18.1.0.625.qdz	2018/9/13 下午 07:47	QDZ 檔案	1,198,688...
下載	max10-18.1.0.625.qdz	2018/9/13 下午 07:47	QDZ 檔案	338,866 KB
110上學期	ModelSimSetup-18.1.0.625-windows	2018/9/14 上午 10:07	應用程式	1,162,110...
CodingFrenzy@mcu03.arping.me	QuartusHelpSetup-18.1.0.625-windows	2018/9/14 上午 09:49	應用程式	311,663 KB
Quartus-lite-18.1.0.625-windows	QuartusLiteSetup-18.1.0.625-windows	2018/9/14 上午 10:33	應用程式	1,776,622...
Setup				



Software Installation

- The first page of installing


QuartusLiteSetup-18.1.0.625-windows.exe





Software Installation


- License agreement



Software Installation

- Select installation directory in:


C:\intelFPGA_lite\18.1





Software Installation


- Select Components





Software Installation



- Installing






Software Installation

- Installation Complete and 啟動驅動程式安裝





Software Installation

- Installation Complete and 啟動驅動程式安裝




Software Installation

- 啟動驅動程式安裝成功確認(必須插上FPGA板)
- 安裝成功確認方式可點選Tools->Programmer再指定



Software Installation

- 啟動驅動程式安裝(必須插上FPGA板)
 - 若當初安裝Quartus時未安裝，可進入以下檔案子目錄
C:\intelFPGA_lite\18.1\quartus\drivers
點選執行 **DPIInst.exe** 後即可安裝





牛刀小試

- 使用 Quartus® Prime Lite Edition Version 18.1 進行軟體模擬
 - 撰寫 Verilog HDL 電路程式碼
 - 編譯程式及觀看合成電路(RTL Viewer)
 - 撰寫 Verilog HDL 電路測試程式碼(testbench)
 - 執行電路測試程式碼，觀看模擬波形
- 使用 Quartus® Prime Lite Edition Version 18.1 進行硬體模擬