We provide two launch files for <u>EuRoC</u> for monocular and stereo setups:

```
roslaunch svo_ros euroc_mono_imu.launch
roslaunch svo_ros euroc_stereo_imu.launch
```

These launch files read the parameters from <code>param/euroc_mono_imu.yaml</code> and <code>param/euroc_stereo_imu.yaml</code>. The parameters are not necessarily optimal for every sequence, but should be enough as a good starting point.

Staring Position when Playing Bag

The first several images of many EuRoC sequences are not good for initialize SVO, especially for the monocular case. Therefore it is better to start the bag at a later time, for example:

```
rosbag play MH_01_easy.bag -s 50
rosbag play MH_02_easy.bag -s 45
rosbag play V1_01_easy.bag
rosbag play V1_02_medium.bag -s 13
rosbag play V2_01_easy.bag
rosbag play V2_02_medium.bag -s 13
```

This is to avoid, for example, strong rotation for monocular initialization.