
Scorpion Mic Input Modification Fitting Instructions - Issue 1.0
















Carefully remove U1 (SSM2015) from its socket - Note that it is a static sensitive device and should be handled and stored appropriately.

Carefully remove the following components

Resistors; R9, R10, R11, R12, R13, R14, R16, R17, R18

Capacitors; C1, C2, C3, C4, C5, C6, C7, C8, C9, C10

Diodes; CR1, CR2, CR3, CR4

Socket: U1

Ensure that the holes highlighted are free from solder

Carefully remove the knobs by pulling them off

{They should come off quite easily - If they do not pull off easily then remove the coloured knob cap and check to see if they are "collet" knobs with a nut inside the knob}


Remove the pot nuts with a 10mm nut runner


You should now be able to pull off the faceplate

{Be careful not to lose the white plastic washers on the pots.... Some of them may be stuck to the back of the faceplate}

Remove the mic gain pot and desolder the holes.


{Be careful not to damage the circuit board.... If necessary destroy the pot as they only cost a few pence.... The circuit board is irreplaceable...}













Ensure that the holes highlighted are free from solder

Fit the new replacement pot.

Re-fit the faceplate and knobs

Fit the mic input module into the PCB- the pins should line up with the positions indicated - press all the way down onto main PCB

Solder the module in place and cut off the excess pins

It should look like this.....

Replacement of Electrolytic Capacitors

Carefully remove the following components;

CapacitorS; C22, C24, C25, C26, C27, C29, C30, C31 & C32

Replace C22, C24, C25, C26, C27 & C29 with the 100uF / 25v capacitors provided

Replace C30 with the 2u2F / 63v capacitor provided

Replace C31 & C32 with the 220uF / 25v axial capacitors provided

.