

HIVE · GCS MOVING MAP

Main GCS

Pad-crew tablet

Position entry

STATE

Normal


No data yet

Stale data

Trajectory

Signal-lost flag triggers after 8s with no fix, to avoid flagging brief gaps

OFFLINE GRID · NO TILE FETCH



ROCKET

LIVE

Lat 34.6105 · Lon -120.6180

LAUNCH PAD

Lat 34.5989 · Lon -120.6206

GCS

Lat 34.6012 · Lon -120.6273

LEGEND

GCS, fixed

Launch pad, fixed

Rocket, live

HIVE · GCS MOVING MAP

STATE

Normal

No data yet

Stale data

Trajectory

Main GCS

Pad-crew tablet

Position entry

Signal-lost flag triggers after 8s with no fix, to avoid flagging brief gaps

OFFLINE GRID · NO TILE FETCH

ROCKET

No GNSS fix yet

LAUNCH PAD

Lat 34.5989 · Lon -120.6206

GCS

Lat 34.6012 · Lon -120.6273

LEGEND

- GCS, fixed
- Launch pad, fixed
- Rocket, live

HIVE · GCS MOVING MAP

Main GCS

Pad-crew tablet

Position entry

STATE

Normal

No data yet

Stale data


Trajectory

Signal-lost flag triggers after 8s with no fix, to avoid flagging brief gaps

OFFLINE GRID · NO TILE FETCH

GNSS SIGNAL LOST

Last fix 14:02:45 · showing last known position



The map displays a central fixed point labeled 'GCS' with concentric circles representing range. To the right is a fixed launch pad labeled 'PAD'. Further right is a live rocket labeled 'ROCKET'. The rocket's position is shown relative to the GCS and PAD.

ROCKET

GNSS SIGNAL LOST

Last fix 14:02:45

LAUNCH PAD

Lat 34.5989 · Lon -120.6206

GCS


Lat 34.6012 · Lon -120.6273


LEGEND

GCS, fixed

Launch pad, fixed

Rocket, live





HIVE · GCS MOVING MAP

Main GCS

Pad-crew tablet

Position entry

Set fixed reference position

Target

Launch pad

GCS

Input mode

Capture from GNSS

Manual entry

Latitude

34.5989

Longitude

-120.6206

Altitude (m)

98

Save & return to map